
Ironic Python Agent Documentation

Release 9.8.1.dev1

OpenStack Foundation

Nov 30, 2023

CONTENTS

1	Overview	1
2	Contents	3
2.1	Installing Ironic Python Agent	3
2.1.1	Image Builders	3
2.1.2	IPA Flags	3
2.1.3	IPA and TLS	3
2.1.4	Hardware Managers	5
2.2	Ironic Python Agent Administration	5
2.2.1	How it works	5
2.2.2	Built-in hardware managers	10
2.2.3	Custom hardware managers	13
2.2.4	Rescue mode	14
2.2.5	Troubleshooting Ironic-Python-Agent (IPA)	15
2.3	Contributing to Ironic Python Agent	20
2.3.1	Hardware Managers	20
2.3.2	Emitting metrics from Ironic-Python-Agent (IPA)	25
2.3.3	Rescue Mode	26
2.3.4	Generated Developer Documentation	27
3	Indices and tables	83
	Python Module Index	85
	Index	87

OVERVIEW

Ironic Python Agent (often abbreviated as IPA) is an agent for controlling and deploying [Ironic](#) controlled baremetal nodes. Typically run in a ramdisk, the agent exposes a REST API for provisioning servers.

2.1 Installing Ironic Python Agent

2.1.1 Image Builders

Unlike most other python software, you must build or download an IPA ramdisk image before use. This is because its not installed in an operating system, but instead is run from within a ramdisk.

Two kinds of images are published on every commit from every branch of IPA:

- **DIB** images are suitable for production usage and can be downloaded from <https://tarballs.openstack.org/ironic-python-agent/dib/files/>.
- **TinyIPA** images are suitable for CI and testing environments and can be downloaded from <https://tarballs.openstack.org/ironic-python-agent/tinyipa/files/>.

If you need to build your own image, use the tools from the [ironic-python-agent-builder](#) project.

2.1.2 IPA Flags

You can pass a variety of flags to IPA on start up to change its behavior.

- `--debug`: Enables debug logging.

2.1.3 IPA and TLS

Client Configuration

During its operation IPA makes HTTP requests to a number of other services, currently including

- `ironic` for lookup/heartbeats
- `ironic-inspector` to publish results of introspection
- HTTP image storage to fetch the user image to be written to the nodes disk (Object storage service or other service storing user images when `ironic` is running in a standalone mode)

When these services are configured to require TLS-encrypted connections, IPA can be configured to either properly use such secure connections or ignore verifying such TLS connections.

Configuration mostly happens in the IPA config file (default is `/etc/ironic_python_agent/ironic_python_agent.conf`, can also be any file placed in `/etc/ironic-python-agent.d`) or

command line arguments passed to `ironic-python-agent`, and it is possible to provide some options via kernel command line arguments instead.

Available options in the [DEFAULT] config file section are:

insecure

Whether to verify server TLS certificates. When not specified explicitly, defaults to the value of `ipa-insecure` kernel command line argument (converted to boolean). The default for this kernel command line argument is taken to be `False`. Overriding it to `True` by adding `ipa-insecure=1` to the value of `[pxe]pxe_append_params` in ironic configuration file will allow running the same IPA-based deploy ramdisk in a CI-like environment when services are using secure HTTPS endpoints with self-signed certificates without adding a custom CA file to the deploy ramdisk (see below).

cafile

Path to the PEM encoded Certificate Authority file. When not specified, available system-wide list of CAs will be used to verify server certificates. Thus in order to use IPA with HTTPS endpoints of other services in a secure fashion (with `insecure` option being `False`, see above), operators should either ensure that certificates of those services are verifiable by root CAs present in the deploy ramdisk, or add a custom CA file to the ramdisk and set this IPA option to point to this file at ramdisk build time.

certfile

Path to PEM encoded client certificate cert file. This option must be used when services are configured to require client certificates on SSL-secured connections. This cert file must be added to the deploy ramdisk and path to it specified for IPA via this option at ramdisk build time. This option has an effect only when the `keyfile` option is also set.

keyfile

Path to PEM encoded client certificate key file. This option must be used when services are configured to require client certificates on SSL-secured connections. This key file must be added to the deploy ramdisk and path to it specified for IPA via this option at ramdisk build time. This option has an effect only when the `certfile` option is also set.

Currently a single set of `cafile/certfile/keyfile` options is used for all HTTP requests to the other services.

Server Configuration

Starting with the Victoria release, the API provided by `ironic-python-agent` can also be secured via TLS. There are two options to do that:

Automatic TLS

This option is enabled by default if no other options are enabled. If ironic supports API version 1.68, a new self-signed TLS certificate will be generated in runtime and sent to ironic on heartbeat.

No special configuration is required on the ironic side.

Manual TLS

If you need to provide your own TLS certificate, you can configure it when building an image. Set the following options in the `ironic-python-agent` configuration file:

```
[DEFAULT]
listen_tls = True
advertise_protocol = https
# Disable automatic TLS.
```

(continues on next page)

(continued from previous page)

```
enable_auto_tls = False

[ssl]
# Certificate and private key file paths (on the ramdisk).
cert_file = /path/to/certificate
# The private key must not be password-protected!
key_file = /path/to/private/key
# Optionally, authenticate connecting clients (i.e. ironic conductors).
#ca_file = /path/to/ca
```

If using DIB to build the ramdisk, use the `ironic-python-agent-tls` element to automate these steps.

On the ironic side you have two options:

- If the certificate can pass host validation, i.e. contains the correct host name or IP address of the agent, add its path to each node with:

```
baremetal node set <node> --driver-info agent_verify_ca=/path/to/ca/
↪or/certificate
```

- Usually, the IP address of the agent is not known in advance, so you need to disable host validation instead:

```
baremetal node set <node> --driver-info agent_verify_ca=False
```

2.1.4 Hardware Managers

Hardware managers are how IPA supports multiple different hardware platforms in the same agent. Any action performed on hardware can be overridden by deploying your own hardware manager.

Custom hardware managers allow you to include hardware-specific tools, files and cleaning steps in the Ironic Python Agent. For example, you could include a BIOS flashing utility and BIOS file in a custom ramdisk. Your custom hardware manager could expose a cleaning step that calls the flashing utility and flashes the packaged BIOS version (or even download it from a tested web server).

Operators wishing to build their own hardware managers should reference the documentation available at *Hardware Managers*.

2.2 Ironic Python Agent Administration

2.2.1 How it works

Integration with Ironic

For information on how to install and configure Ironic drivers, including drivers for IPA, see the [Ironic drivers documentation](#).

Lookup

On startup, the agent performs a lookup in Ironic to determine its node UUID by sending a hardware profile to the Ironic lookup endpoint: `/v1/lookup`.

Heartbeat

After successfully looking up its node, the agent heartbeats via `/v1/heartbeat/{node_ident}` every N seconds, where N is the Ironic conductors `agent.heartbeat_timeout` value multiplied by a number between .3 and .6.

For example, if your conductors `ironic.conf` contains:

```
[agent]
heartbeat_timeout = 60
```

IPA will heartbeat between every 20 and 36 seconds. This is to ensure jitter for any agents reconnecting after a network or API disruption.

After the agent heartbeats, the conductor performs any actions needed against the node, including querying status of an already run command. For example, initiating in-band cleaning tasks or deploying an image to the node.

Inspection

IPA can conduct hardware inspection on start up and post data to the [Ironic Inspector](#) via the `/v1/continue` endpoint.

Edit your default PXE/iPXE configuration or IPA options baked in the image, and set `ipa-inspection-callback-url` to the full endpoint of Ironic Inspector, for example:

```
ipa-inspection-callback-url=http://IP:5050/v1/continue
```

Make sure your DHCP environment is set to boot IPA by default.

For the cases where the infrastructure operator and cloud user are the same, an additional tool exists that can be installed alongside the agent inside a running instance. This is the `ironic-collect-introspection-data` command which allows for a node in ACTIVE state to publish updated introspection data to `ironic-inspector`. This ability requires `ironic-inspector` to be configured with `[processing]permit_active_introspection` set to True. For example:

```
ironic-collect-introspection-data --inspection_callback_url http://IP:5050/v1/
↪continue
```

Alternatively, this command may also be used with multicast DNS functionality to identify the Ironic Inspector service endpoint. For example:

```
ironic-collect-introspection-data --inspection_callback_url mdns
```

An additional daemon mode may be useful for some operators who wish to receive regular updates, in the form of the `[DEFAULT]introspection_daemon` boolean configuration option. For example:

```
ironic-collect-introspection-data --inspection_callback_url mdns --  
->introspection_daemon
```

The above command will attempt to connect to introspection and will then enter a loop to publish every 300 seconds. This can be tuned with the `[DEFAULT]introspection_daemon_post_interval` configuration option.

Inspection Data

As part of the inspection process, data is collected on the machine and sent back to [Ironic Inspector](#) for storage. It can be accessed via the [introspection data API](#).

The exact format of the data depends on the enabled *collectors*, which can be configured using the `ipa-inspection-collectors` kernel parameter. Each collector appends information to the resulting JSON object. The in-tree collectors are:

default

The default enabled collectors. Collects the following keys:

- `inventory` - *Hardware Inventory*.
- `root_disk` - The default root device for this machine, which will be used for deployment if root device hints are not provided.
- `configuration` - Inspection configuration, an object with two keys:
 - `collectors` - List of enabled collectors.
 - `managers` - List of enabled *Hardware Managers*: items with keys `name` and `version`.
- `boot_interface` - Deprecated, use the `inventory.boot.pxe_interface` field.

logs

Collect system logs. To yield useful results it must always go last in the list of collectors. Provides one key:

- `logs` - base64 encoded tarball with various logs.

pci-devices

Collects the list of PCI devices. Provides one key:

- `pci_devices` - list of objects with keys `vendor_id` and `product_id`.

extra-hardware

Collects a vast list of facts about the systems, using the [hardware](#) library, which is a required dependency for this collector. Adds one key:

- `data` - raw data from the `hardware-collect` utility. Is a list of lists with 4 items each. It is recommended to use this collector together with the `extra_hardware` processing hook on the Ironic Inspector side to convert it to a nested dictionary in the `extra` key.

If `ipa-inspection-benchmarks` is set, the corresponding benchmarks are executed and their result is also provided.

dmi-decode

Collects information from `dmidecode`. Provides one key:

- `dmi` DMI information in three keys: `bios`, `cpu` and `memory`.

numa-topology

Collects NUMA topology information. Provides one key:

- `numa_topology` with three nested keys:
 - `ram` - list of objects with keys `numa_node` (node ID) and `size_kb`.
 - `cpus` - list of objects with keys `cpu` (CPU ID), `numa_node` (node ID) and `thread_siblings` (list of sibling threads).
 - `nics` - list of objects with keys `name` (NIC name) and `numa_node` (node ID).

lldp

Collects information about the network connectivity using LLDP. Provides one key:

- `lldp_raw` - mapping of interface names to lists of raw type-length-value (TLV) records.

Hardware Inventory

IPA collects various hardware information using its *Hardware Managers*, and sends it to Ironic on lookup and to Ironic Inspector on *Inspection*.

The exact format of the inventory depends on the hardware manager used. Here is the basic format expected to be provided by all hardware managers. The inventory is a dictionary (JSON object), containing at least the following fields:

cpu

CPU information: `model_name`, `frequency`, `count`, `architecture` and `flags`.

memory

RAM information: `total` (total size in bytes), `physical_mb` (physically installed memory size in MiB, optional).

Note: The difference is that the latter includes the memory region reserved by the kernel and is always slightly bigger. It also matches what the Nova flavor would contain for this node and thus is used by the inspection process instead of `total`.

bmc_address

IPv4 address of the nodes BMC (aka IPMI v4 address), optional.

bmc_v6address

IPv6 address of the nodes BMC (aka IPMI v6 address), optional.

disks

list of disk block devices with fields: `name`, `model`, `size` (in bytes), `rotational` (boolean), `wwn`, `serial`, `uuid`, `vendor`, `wwn_with_extension`, `wwn_vendor_extension`, `hctl` and `by_path` (the full disk path, in the form `/dev/disk/by-path/<rest-of-path>`).

interfaces

list of network interfaces with fields: `name`, `mac_address`, `ipv4_address`, `lldp`, `vendor`, `product`, and optionally `biosdevname` (BIOS given NIC name) and `speed_mbps` (maximum supported speed).

Note: For backward compatibility, interfaces may contain `lldp` fields. They are deprecated, consumers should rely on the `lldp` inspection collector instead.

system_vendor

system vendor information from SMBIOS as reported by `dmidecode`: `product_name`, `serial_number` and `manufacturer`, as well as a `firmware` structure with fields `vendor`, `version` and `build_date`.

boot

boot information with fields: `current_boot_mode` (boot mode used for the current boot - BIOS or UEFI) and `pxe_interface` (interface used for PXE booting, if any).

hostname

hostname for the system

Note: This is most likely to be set by the DHCP server. Could be `localhost` if the DHCP server does not set it.

Image Checksums

As part of the process of downloading images to be written to disk as part of image deployment, a series of fields are utilized to determine if the image which has been downloaded matches what the user stated as the expected image checksum utilizing the `instance_info/image_checksum` value.

OpenStack, as a whole, has replaced the legacy `checksum` field with `os_hash_value` and `os_hash_algo` fields, which allows for an image checksum and value to be asserted. An advantage of this is a variety of algorithms are available, if a user/operator is so-inclined.

For the purposes of Ironic, we continue to support the pass-through checksum field as we support the checksum being retrieved via a URL.

We also support determining the checksum by length.

The field can be utilized to designate:

- A URL to retrieve a checksum from.
- MD5 (Disabled by default, see `[DEFAULT]md5_enabled` in the agent configuration file.)
- SHA-2 based SHA256
- SHA-2 based SHA512

SHA-3 based checksums are not supported for auto-determination as they can have a variable length checksum result. At of when this documentation was added, SHA-2 based checksum algorithms have not been withdrawn from approval. If you need to force use of SHA-3 based checksums, you *must* utilize the `os_hash_algo` setting along with the `os_hash_value` setting.

2.2.2 Built-in hardware managers

GenericHardwareManager

This is the default hardware manager for ironic-python-agent. It provides support for *Hardware Inventory* and the default deploy, clean, and service steps.

Deploy steps

deploy.write_image(node, ports, image_info, configdrive=None)

A deploy step backing the `write_image` deploy step of the [direct deploy interface](#). Should not be used explicitly, but can be overridden to provide a custom way of writing an image.

deploy.erase_devices_metadata(node, ports)

Erases partition tables from all recognized disk devices. Can be used with software RAID since it requires empty holder disks.

raid.apply_configuration(node, ports, raid_config, delete_existing=True)

Apply a software RAID configuration. It belongs to the `raid` interface and must be used through the [ironic RAID feature](#).

Injecting files

deploy.inject_files(node, ports, files, verify_ca=True)

This optional deploy step (introduced in the Wallaby release series) allows injecting arbitrary files into the node. The list of files is built from the optional `inject_files` property of the node concatenated with the explicit `files` argument. Each item in the list is a dictionary with the following fields:

path (required)

An absolute path to the file on the target partition. All missing directories will be created.

partition

Specifies the target partition in one of 3 ways:

- A number is treated as a partition index (starting with 1) on the root device.
- A path is treated as a block device path (e.g. `/dev/sda1` or `/dev/disk/by-partlabel/<something>`).
- If missing, the agent will try to find a partition containing the first component of the `path` on the root device. E.g. for `/etc/sysctl.d/my.conf`, look for a partition containing `/etc`.

deleted

If `True`, the file is deleted, not created. Incompatible with `content`.

content

Data to write. Incompatible with `deleted`. Can take two forms:

- A URL of the content. Can use Python-style formatting to build a node specific URL, e.g. `http://server/{node[uuid]}/{ports[0][address]}`.
- Base64 encoded binary contents.

mode, owner, group

Numeric mode, owner ID and group ID of the file.

dirmode

Numeric mode of the leaf directory if it has to be created.

This deploy step is disabled by default and can be enabled via a deploy template or via the `ipa-inject-files-priority` kernel parameter.

Known limitations:

- Names are not supported for `owner` and `group`.
- LVM is not supported.

Clean steps

deploy.burnin_cpu

Stress-test the CPUs of a node via stress-ng for a configurable amount of time. Disabled by default.

deploy.burnin_disk

Stress-test the disks of a node via fio. Disabled by default.

deploy.burnin_memory

Stress-test the memory of a node via stress-ng for a configurable amount of time. Disabled by default.

deploy.burnin_network

Stress-test the network of a pair of nodes via fio for a configurable amount of time. Disabled by default.

deploy.erase_devices

Securely erases all information from all recognized disk devices. Relatively fast when secure ATA erase is available, otherwise can take hours, especially on a virtual environment. Enabled by default.

deploy.erase_devices_metadata

Erases partition tables from all recognized disk devices. Can be used as an alternative to the much longer `erase_devices` step.

deploy.erase_pstore

Erases entries from pstore, the kernels oops/panic logger. Disabled by default. Can be enabled via priority overrides.

raid.create_configuration

Create a RAID configuration. This step belongs to the `raid` interface and must be used through the [ironic RAID feature](#).

raid.delete_configuration

Delete the RAID configuration. This step belongs to the `raid` interface and must be used through the [ironic RAID feature](#).

Service steps

Service steps can be invoked by an operator of a baremetal node, to modify or perform some intermediate action outside the realm of normal use of a deployed bare metal instance. This is similar in form of interaction to cleaning, and ultimately some cleaning and deployment steps *are* available to be used.

deploy.burnin_cpu

Stress-test the CPUs of a node via stress-ng for a configurable amount of time.

deploy.burnin_memory

Stress-test the memory of a node via stress-ng for a configurable amount of time.

deploy.burnin_network

Stress-test the network of a pair of nodes via fio for a configurable amount of time.

raid.create_configuration

Create a RAID configuration. This step belongs to the `raid` interface and must be used through the [ironic RAID feature](#).

raid.apply_configuration(node, ports, raid_config, delete_existing=True)

Apply a software RAID configuration. It belongs to the `raid` interface and must be used through the [ironic RAID feature](#).

raid.delete_configuration

Delete the RAID configuration. This step belongs to the `raid` interface and must be used through the [ironic RAID feature](#).

deploy.write_image(node, ports, image_info, configdrive=None)

A step backing the `write_image` deploy step of the [direct deploy interface](#). Should not be used explicitly, but can be overridden to provide a custom way of writing an image.

deploy.inject_files(node, ports, files, verify_ca=True)

A step to inject files into a system. Specifically this step is documented earlier in this documenta-tion.

Note: The Ironic Developers chose to limit the items available for service steps such that the risk of data destruction is generally minimized. That being said, it could be reasonable to reconfigure RAID devices through local hardware managers *or* to write the base OS image as part of a service operation. As such, caution should be taken, and if additional data erasure steps are needed you may want to consider moving a node through cleaning to remove the workload. Otherwise, if you have a use case, please feel free to reach out to the Ironic Developers so we can understand and enable your use case.

Cleaning safeguards

The stock hardware manager contains a number of safeguards to prevent unsafe conditions from occurring.

Devices Skip List

A list of devices that Ironic does not touch during the cleaning and deployment process can be specified in the node properties field under `skip_block_devices`. This should be a list of dictionaries containing hints to identify the drives. For example:

```
'skip_block_devices': [{'name': '/dev/vda', 'vendor': '0x1af4'}]
```

To prevent software RAID devices from being deleted, put their volume name (defined in the `target_raid_config`) to the list.

Note: one dictionary with one value for each of the logical disks. For example:

```
'skip_block_devices': [{'volume_name': 'large'}, {'volume_name': 'temp'}]
```

Shared Disk Cluster Filesystems

Commonly used shared disk cluster filesystems, when detected, causes cleaning processes on stock hardware manager methods to abort prior to destroying the contents on the disk.

These filesystems include IBM General Parallel File System (GPFS), VmWare Virtual Machine File System (VMFS), and Red Hat Global File System (GFS2).

For information on troubleshooting, and disabling this check, see *Troubleshooting Ironic-Python-Agent (IPA)*.

2.2.3 Custom hardware managers

MellanoxDeviceHardwareManager

This is a custom hardware manager for `ironic-python-agent`. It provides support for Nvidia/Mellanox NICs.

- You can get the binraies firmware for all Nvidia/Mellanox NICs from here [Nvidia firmware downloads](#)
- And you can get the deviceID from here [Nvidia/Mellanox NICs list](#)
- Also you can check here [MFT documentation](#) for some supported parameters

Clean steps

```
update_nvidia_nic_firmware_image(node, ports, images)
```

A clean step used to update Nvidia/Mellanox NICs firmware images from the required parameter `images` list. its disabled by default. Each image in the list is a dictionary with the following fields:

url (required)

The url of the firmware image (`file://`, `http://`).

checksum (required)

checksum of the provided image.

checksumType (required)

checksum type, it could be (md5/sha512/sha256).

componentFlavor (required)

The PSID of the nic.

version (required)

version of the firmware image , it must be the same as in the image file.

update_nvidia_nic_firmware_settings(node, ports, settings)

A clean step used to update Nvidia/Mellanox NICs firmware settings from the required parameter settings list. its disabled by default. Each settings in the list is a dictionary with the following fields:

deviceID (required)

The ID of the NIC

globalConfig

The global configuration for NIC

function0Config

The per-function configuration of the first port of the NIC

function1Config

The per-function configuration of the second port of the NIC

Service steps

The Clean steps supported by the MellanoxDeviceHardwareManager are also available as Service steps if an infrastructure operator wishes to apply new firmware for a running machine.

2.2.4 Rescue mode

Overview

Rescue mode is a feature that can be used to boot a ramdisk for a tenant in case the machine is otherwise inaccessible. For example, if theres a disk failure that prevents access to another operating system, rescue mode can be used to diagnose and fix the problem.

Support in ironic-python-agent images

Rescue is initiated when ironic-conductor sends the `finalize_rescue` command to ironic-python-agent. A user `rescue` is created with a password provided as an argument to this command. DHCP is then configured to facilitate network connectivity, thus enabling a user to login to the machine in rescue mode.

Warning: Rescue mode exposes the contents of the ramdisk to the tenant. Ensure that any rescue image you build does not contain secrets (e.g. sensitive clean steps, proprietary firmware blobs).

The below has information about supported images that may be built to use rescue mode.

DIB

The DIB image supports rescue mode when used with DHCP tenant networks.

After the `finalize_rescue` command completes, DHCP will be configured on all network interfaces, and a `rescue` user will be created with the specified `rescue_password`.

TinyIPA

The TinyIPA image supports rescue mode when used with DHCP tenant networks. No special action is required to build a TinyIPA image with this support.

After the `finalize_rescue` command completes, DHCP will be configured on all network interfaces, and a `rescue` user will be created with the specified `rescue_password`.

2.2.5 Troubleshooting Ironic-Python-Agent (IPA)

This document contains basic trouble shooting information for IPA.

Gaining Access to IPA on a node

In order to access a running IPA instance a user must be added or enabled on the image. Below we will cover several ways to do this.

Access via ssh

`ironic-python-agent-builder`

SSH access can be added to DIB built IPA images with the `dynamic-login`⁰ or the `devuser` element¹

The `dynamic-login` element allows the operator to inject a SSH key when the image boots. Kernel command line parameters are used to do this.

`dynamic-login` element example:

- Add `sshkey="ssh-rsa BBA1..."` to `kernel_append_params` setting in the `ironic.conf` file
- Restart the `ironic-conductor` with the command `service ironic-conductor restart`

Install `ironic-python-agent-builder` following the guide²

`devuser` element example:

```
export DIB_DEV_USER_USERNAME=username
export DIB_DEV_USER_PWDLESS_SUDO=yes
export DIB_DEV_USER_AUTHORIZED_KEYS=$HOME/.ssh/id_rsa.pub
ironic-python-agent-builder -o /path/to/custom-ipa -e devuser debian
```

⁰ *Dynamic-login DIB element*: https://github.com/openstack/diskimage-builder/tree/master/diskimage_builder/elements/dynamic-login

¹ *DevUser DIB element*: https://github.com/openstack/diskimage-builder/tree/master/diskimage_builder/elements/devuser

² *ironic-python-agent-builder*: <https://docs.openstack.org/ironic-python-agent-builder/latest/install/index.html>

tinyipa

If you want to enable SSH access to the image, set `AUTHORIZE_SSH` variable in your shell to `true` before building the tinyipa image:

```
export AUTHORIZE_SSH=true
```

By default it will use default public RSA (or, if not available, DSA) key of the user running the build (`~/.ssh/id_{rsa,dsa}.pub`).

To provide other public SSH key, export full path to it in your shell before building tinyipa as follows:

```
export SSH_PUBLIC_KEY=/path/to/other/ssh/public/key
```

The user to use for access is default Tiny Core Linux user `tc`. This user has no password and has password-less `sudo` permissions. Installed SSH server is configured to disable Password authentication.

Access via console

If you need to use console access, passwords must be enabled there are a couple ways to enable this depending on how the IPA image was created:

ironic-python-agent-builder

Users wishing to use password access can be add the `dynamic-login`^{Page 15, 0} or the `devuser` element^{Page 15, 1}

The `dynamic-login` element allows the operator to change the root password dynamically when the image boots. Kernel command line parameters are used to do this.

`dynamic-login` element example:

```
Generate a ENCRYPTED_PASSWORD with the openssl passwd -1 command
Add rootpwd="$ENCRYPTED_PASSWORD" value on the kernel_append_params setting.
->in /etc/ironic/ironic.conf
Restart the ironic-conductor with the command service ironic-conductor restart
```

Users can also be added to DIB built IPA images with the `devuser` element^{Page 15, 1}

Install `ironic-python-agent-builder` following the guide^{Page 15, 2}

Example:

```
export DIB_DEV_USER_USERNAME=username
export DIB_DEV_USER_PWDLESS_SUDO=yes
export DIB_DEV_USER_PASSWORD=PASSWORD
ironic-python-agent-builder -o /path/to/custom-ipa -e devuser debian
```

tinyipa

The image built with scripts provided in `tinyipa` folder of [Ironic Python Agent Builder](#) repository by default auto-logs the default Tiny Core Linux user `tc` to the console. This user has no password and has password-less `sudo` permissions.

How to pause the IPA for debugging

When debugging issues with the IPA, in particular with cleaning, it may be necessary to log in to the RAM disk before the IPA actually starts (and delay the launch of the IPA). One easy way to do this is to set `maintenance` on the node and then trigger cleaning. Ironic will boot the node into the RAM disk, but the IPA will stall until the maintenance state is removed. This opens a time window to log into the node.

Another way to do this is to add simple cleaning steps in a custom hardware manager which sleep until a certain condition is met, e.g. until a given file exists. Having multiple of these barrier steps allows to go through the cleaning steps and have a break point in between them.

Set IPA to debug logging

Debug logging can be enabled a several different ways. The easiest way is to add `ipa-debug=1` to the kernel command line. To do this:

- Append `ipa-debug=1` to the `kernel_append_params` setting in the `ironic.conf` file
- Restart the ironic-conductor with the command `service ironic-conductor restart`

If the system is running and uses `systemd` then editing the services file will be required.

- `systemctl edit ironic-python-agent.service`
- Append `--debug` to end of the `ExecStart` command
- Restart IPA. See the *Manually restart IPA* section below.

Where can I find the IPA logs

Retrieving the IPA logs will differ depending on which base image was used.

- Operating system that do not use `systemd` (ie Ubuntu 14.04)
 - logs will be found in the `/var/log/` folder.
- Operating system that do use `systemd` (ie Fedora, CentOS, RHEL)
 - logs may be viewed with `sudo journalctl -u ironic-python-agent`
 - if using a `diskimage-builder` ramdisk, it may be configured to output all contents of the journal, including `ironic-python-agent` logs, by enabling the [journal-to-console](#) element.

In addition, Ironic is configured to retrieve IPA logs upon failures by default, you can learn more about this feature in the [Ironic troubleshooting guide](#).

Manually restart IPA

In some cases it is helpful to enable debug mode on a running node. If the system does not use systemd then IPA can be restarted directly:

```
sudo /usr/local/bin/ironic-python-agent [--debug]
```

If the system uses systemd then systemctl can be used to restart the service:

```
sudo systemctl restart ironic-python-agent.service
```

Cleaning halted with ProtectedDeviceError

The IPA service has halted cleaning as one of the block devices within or attached to the bare metal node contains a class of filesystem which **MAY** cause irreparable harm to a potentially running cluster if accidentally removed.

These filesystems *may* be used for only local storage and as a result be safe to erase. However if a shared block device is in use, such as a device supplied via a Storage Area Network utilizing protocols such as iSCSI or FibreChannel. Ultimately the Host Bus Adapter (HBA) may not be an entirely detectable entity given the hardware market place and aspects such as SmartNICs and Converged Network Adapters with specific offload functions to support standards like NVMe over Fabric (NVMe-oF).

By default, the agent will prevent these filesystems from being deleted and will halt the cleaning process when detected. The cleaning process can be re-triggered via Ironics state machine once one of the documented settings have been used to notify the agent that no action is required.

What filesystems are looked for

IBM General Parallel Filesystem
Red Hat Global Filesystem 2
VmWare Virtual Machine FileSystem (VMFS)

Im okay with deleting, how do I tell IPA to clean the disk(s)?

Four potential ways exist to signal to IPA. Please note, all of these options require access either to the node in Ironics API or ability to modify Ironic configuration.

Via Ironic

Note: This option requires that the version of Ironic be sufficient enough to understand and explicitly provide this option to the Agent.

Inform Ironic to provide the option to the Agent:

```
baremetal node set --driver-info wipe_special_filesystems=True
```

Via a nodes kernel_append_params setting

This may be set on a node level by utilizing the override kernel_append_params setting which can be utilized on a node level. Example:

```
baremetal node set --driver-info kernel_append_params="ipa-guard-special-  
↔filesystems=False"
```

Alternatively, if you wish to set this only once, you may use the instance_info field, which is wiped upon teardown of the node. Example:

```
baremetal node set --instance-info kernel_append_params="ipa-guard-special-  
↔filesystems=False"
```

Via Ironics Boot time PXE parameters (Globally)

Globally, this setting may be passed by modifying the `ironic.conf` configuration file on your cluster by adding `ipa-guard-special-filefilesystems=False` string to the `[pxe]kernel_append_params` parameter.

Warning: If your running a multi-conductor deployment, all of your `ironic.conf` configuration files will need to be updated to match.

Via Ramdisk configuration

This option requires modifying the ramdisk, and is the most complex, but may be advisable if you have a mixed environment cluster where shared clustered filesystems may be a concern on some machines, but not others.

Warning: This requires rebuilding your agent ramdisk, and modifying the embedded configuration file for the `ironic-python-agent`. If your confused at all by this statement, this option is not for you.

Edit `/etc/ironic_python_agent/ironic_python_agent.conf` and set the parameter `[DEFAULT]guard_special_filesystems` to `False`.

References

2.3 Contributing to Ironic Python Agent

Ironic Python Agent is an agent for controlling and deploying Ironic controlled baremetal nodes. Typically run in a ramdisk, the agent exposes a REST API for provisioning servers.

Throughout the remainder of the document, Ironic Python Agent will be abbreviated to IPA.

2.3.1 Hardware Managers

Hardware managers are how IPA supports multiple different hardware platforms in the same agent. Any action performed on hardware can be overridden by deploying your own hardware manager.

IPA ships with *GenericHardwareManager*, which implements basic cleaning and deployment methods compatible with most hardware.

Warning: Some functionality inherent in the stock hardware manager cleaning methods may be useful in custom hardware managers, but should not be inherently expected to also work in custom managers. Examples of this are clustered filesystem protections, and cleaning method fallback logic. Custom hardware manager maintainers should be mindful when overriding the stock methods.

How are methods executed on HardwareManagers?

Methods that modify hardware are dispatched to each hardware manager in priority order. When a method is dispatched, if a hardware manager does not have a method by that name or raises *IncompatibleHardwareMethodError*, IPA continues on to the next hardware manager. Any hardware manager that returns a result from the method call is considered a success and its return value passed on to whatever dispatched the method. If the method is unable to run successfully on any hardware managers, *HardwareManagerMethodNotFound* is raised.

Why build a custom HardwareManager?

Custom hardware managers allow you to include hardware-specific tools, files and cleaning steps in the Ironic Python Agent. For example, you could include a BIOS flashing utility and BIOS file in a custom ramdisk. Your custom hardware manager could expose a cleaning step that calls the flashing utility and flashes the packaged BIOS version (or even download it from a tested web server).

How can I build a custom HardwareManager?

In general, custom HardwareManagers should subclass `hardware.HardwareManager`. Subclassing `hardware.GenericHardwareManager` should only be considered if the aim is to raise the priority of all methods of the `GenericHardwareManager`. The only required method is `evaluate_hardware_support()`, which should return one of the enums in `hardware.HardwareSupport`. Hardware support determines which hardware manager is executed first for a given function (see: *How are methods executed on HardwareManagers?* for more info). Common methods you may want to implement are `list_hardware_info()`, to add additional hardware the `GenericHardwareManager` is unable to identify and `erase_devices()`, to erase devices in ways other than ATA secure erase or shredding.

Some reusable functions are provided by `ironic-lib`, its IPA is relatively stable.

The `examples` directory has two example hardware managers that can be copied and adapted for your use case.

Custom HardwareManagers and Cleaning

One of the reasons to build a custom hardware manager is to expose extra steps in **Ironic Cleaning**. A node will perform a set of cleaning steps any time the node is deleted by a tenant or moved from manageable state to available state. Ironic will query IPA for a list of clean steps that should be executed on the node. IPA will dispatch a call to `get_clean_steps()` on all available hardware managers and then return the combined list to Ironic.

To expose extra clean steps, the custom hardware manager should have a function named `get_clean_steps()` which returns a list of dictionaries. The dictionaries should be in the form:

```
def get_clean_steps(self, node, ports):
    return [
        {
            # A function on the custom hardware manager
            'step': 'upgrade_firmware',
            # An integer priority. Largest priorities are executed first
            'priority': 10,
            # Should always be the deploy interface
            'interface': 'deploy',
            # Request the node to be rebooted out of band by Ironic when
            # the step completes successfully
            'reboot_requested': False
        }
    ]
```

Then, you should create functions which match each of the `step` keys in the clean steps you return. The functions will take two parameters: `node`, a dictionary representation of the Ironic node, and `ports`, a list of dictionary representations of the Ironic ports attached to `node`.

When a clean step is executed in IPA, the `step` key will be sent to the hardware managers in hardware support order, using `hardware.dispatch_to_managers()`. For each hardware manager, if the manager has a function matching the `step` key, it will be executed. If the function returns a value (including `None`), that value is returned to Ironic and no further managers are called. If the function raises `IncompatibleHardwareMethodError`, the next manager will be called. If the function raises any other exception, the command will be considered failed, the command results error message will be set to the exceptions error message, and no further managers will be called. An example step:

```
def upgrade_firmware(self, node, ports):
    if self._device_exists():
        # Do the upgrade
        return 'upgraded firmware'
    else:
        raise errors.IncompatibleHardwareMethodError()
```

If the step has args, you need to add them to `argsinfo` and provide the function with extra parameters.

```
def get_clean_steps(self, node, ports):
    return [
        {
            # A function on the custom hardware manager
            'step': 'upgrade_firmware',
            # An integer priority. Largest priorities are executed first
            'priority': 10,
            # Should always be the deploy interface
            'interface': 'deploy',
            # Arguments that can be required or optional.
            'argsinfo': {
                'firmware_url': {
                    'description': 'Url for firmware',
                    'required': True,
                },
            }
            # Request the node to be rebooted out of band by Ironic when
            # the step completes successfully
            'reboot_requested': False
        }
    ]
```

```
def upgrade_firmware(self, node, ports, firmware_url):
    if self._device_exists():
        # Do the upgrade
        return 'upgraded firmware'
    else:
        raise errors.IncompatibleHardwareMethodError()
```

Note: If two managers return steps with the same *step* key, the priority will be set to whichever manager has a higher hardware support level and then use the higher priority in the case of a tie.

In some cases, it may be necessary to create a customized cleaning step to take a particular pattern of behavior. Those doing such work may want to leverage file system safety checks, which are part of the stock hardware managers.

```
def custom_erase_devices(self, node, ports):
    for dev in determine_my_devices_to_erase():
        hardware.safety_check_block_device(node, dev.name)
        my_special_cleaning(dev.name)
```

Custom HardwareManagers and Deploying

Starting with the Victoria release cycle, `deployment` can be customized similarly to `cleaning`. A hardware manager can define *deploy steps* that may be run during deployment by exposing a `get_deploy_steps` call.

There are two kinds of deploy steps:

1. Steps that need to be run automatically must have a non-zero priority and cannot take required arguments. For example:

```
def get_deploy_steps(self, node, ports):
    return [
        {
            # A function on the custom hardware manager
            'step': 'upgrade_firmware',
            # An integer priority. Largest priorities are executed first
            'priority': 10,
            # Should always be the deploy interface
            'interface': 'deploy',
        }
    ]

# A deploy steps looks the same as a clean step.
def upgrade_firmware(self, node, ports):
    if self._device_exists():
        # Do the upgrade
        return 'upgraded firmware'
    else:
        raise errors.IncompatibleHardwareMethodError()
```

Priority should be picked based on when exactly in the process the step will run. See [agent step priorities](#) for guidance.

2. Steps that will be requested via `deploy templates` should have a priority of 0 and may take both required and optional arguments that will be provided via the deploy templates. For example:

```
def get_deploy_steps(self, node, ports):
    return [
        {
            # A function on the custom hardware manager
            'step': 'write_a_file',
            # Steps with priority 0 don't run by default.
            'priority': 0,
            # Should be the deploy interface, unless there is driver-side
            # support for another interface (as it is for RAID).
            'interface': 'deploy',
            # Arguments that can be required or optional.
            'argsinfo': {
                'path': {
                    'description': 'Path to file',
                    'required': True,
                }
            }
        }
    ]
```

(continues on next page)

(continued from previous page)

```

    },
    'content': {
        'description': 'Content of the file',
        'required': True,
    },
    'mode': {
        'description': 'Mode of the file, defaults to 0644',
        'required': False,
    },
}
}
]

def write_a_file(self, node, ports, path, contents, mode=0o644):
    pass # Mount the disk, write a file.

```

Custom HardwareManagers and Service operations

Starting with the Bobcat release cycle, A hardware manager can define *service steps* that may be run during a service operation by exposing a `get_service_steps` call.

Service steps are intended to be invoked by an operator to perform an ad-hoc action upon a node. This does not include automatic step execution, but may at some point in the future. The result is that steps can be exposed similar to Clean steps and Deploy steps, just the priority value, should be 0 as the user requested order is what is utilized.

```

def get_deploy_steps(self, node, ports):
    return [
        {
            # A function on the custom hardware manager
            'step': 'write_a_file',
            # Steps with priority 0 don't run by default.
            'priority': 0,
            # Should be the deploy interface, unless there is driver-side
            # support for another interface (as it is for RAID).
            'interface': 'deploy',
            # Arguments that can be required or optional.
            'argsinfo': {
                'path': {
                    'description': 'Path to file',
                    'required': True,
                },
                'content': {
                    'description': 'Content of the file',
                    'required': True,
                },
                'mode': {
                    'description': 'Mode of the file, defaults to 0644',
                    'required': False,
                }
            }
        }
    ]

```

(continues on next page)

(continued from previous page)

```
        },
    }
}
]

def write_a_file(self, node, ports, path, contents, mode=0o644):
    pass # Mount the disk, write a file.
```

Versioning

Each hardware manager has a name and a version. This version is used during cleaning to ensure the same version of the agent is used to on a node through the entire process. If the version changes, cleaning is restarted from the beginning to ensure consistent cleaning operations and to make updating the agent in production simpler.

You can set the version of your hardware manager by creating a class variable named `HARDWARE_MANAGER_VERSION`, which should be a string. The default value is 1.0. You should change this version string any time you update your hardware manager. You can also change the name your hardware manager presents by creating a class variable called `HARDWARE_MANAGER_NAME`, which is a string. The name defaults to the class name. Currently IPA only compares version as a string; any version change whatsoever will induce cleaning to restart.

Priority

A hardware manager has a single overall priority, which should be based on how well it supports a given piece of hardware. At load time, IPA executes `evaluate_hardware_support()` on each hardware manager. This method should return an int representing hardware manager priority, based on what it detects about the platform its running on. Suggested values are included in the `HardwareSupport` class. Returning a value of 0 aka `HardwareSupport.NONE`, will prevent the hardware manager from being used. IPA will never ship a hardware manager with a priority higher than 3, aka `HardwareSupport.SERVICE_PROVIDER`.

2.3.2 Emitting metrics from Ironic-Python-Agent (IPA)

This document describes how to emit metrics from IPA, including timers and counters in code to directly emitting hardware metrics from a custom `HardwareManager`.

Overview

IPA uses the metrics implementation from `ironic-lib`, with a few caveats due to the dynamic configuration done at lookup time. You cannot cache the metrics instance as the `MetricsLogger` returned will change after lookup if configs different than the default setting have been used. This also means that the method decorator supported by `ironic-lib` cannot be used in IPA.

Using a context manager

Using the context manager is the recommended way for sending metrics that time or count sections of code. However, given that you cannot cache the MetricsLogger, you have to explicitly call `get_metrics_logger()` from `ironic-lib` every time. For example:

```
from ironic_lib import metrics_utils

def my_method():
    with metrics_utils.get_metrics_logger(__name__).timer('my_method'):
        return _do_work()
```

As a note, these metric collectors do work for custom HardwareManagers as well. However, you may want to metric the portions of a method that determine compatibility separate from portions of a method that actually do work, in order to assure the metrics are relevant and useful on all hardware.

Explicitly sending metrics

A feature that may be particularly helpful for deployers writing custom HardwareManagers is the ability to explicitly send metrics. For instance, you could add a cleaning step which would retrieve metrics about a device and ship them using the provided metrics library. For example:

```
from ironic_lib import metrics_utils

def my_cleaning_step():
    for name, value in _get_smart_data():
        metrics_utils.get_metrics_logger(__name__).send_gauge(name, value)
```

References

For more information, please read the source of the metrics module in `ironic-lib`.

2.3.3 Rescue Mode

Ironic supports putting nodes in rescue mode using hardware types that support rescue interfaces. A rescue operation can be used to boot nodes into a rescue ramdisk so that the rescue user can access the node. This provides the ability to access the node when normal access is not possible. For example, if there is a need to perform manual password reset or data recovery in the event of some failure, a rescue operation can be used. IPA rescue extension exposes a command `finalize_rescue` (that is used by Ironic) to set the password for the rescue user when the rescue ramdisk is booted.

finalize_rescue command

The rescue extension exposes the command `finalize_rescue`; when invoked, it triggers rescue mode:

```
POST /v1/commands
{
  "name": "rescue.finalize_rescue",
  "params": {
    "rescue_password": "p455w0rd"
  }
}
```

`rescue_password` is a required parameter for this command.

Upon success, it returns following data in response:

```
{
  "command_name": "finalize_rescue",
  "command_params": {
    "rescue_password": "p455w0rd"
  },
  "command_status": "SUCCEEDED"
  "command_result": null
  "command_error": null
}
```

If successful, this synchronous command will:

1. Write the salted and crypted `rescue_password` to `/etc/ipa-rescue-config/ipa-rescue-password` in the chroot or filesystem that `ironic-python-agent` is running in.
2. Stop the `ironic-python-agent` process after completing these actions and returning the response to the API request.

2.3.4 Generated Developer Documentation

- [modindex](#)

[ironic_python_agent](#)

[ironic_python_agent package](#)

[Subpackages](#)

[ironic_python_agent.api package](#)

[Submodules](#)

[ironic_python_agent.api.app module](#)

```
class ironic_python_agent.api.app.Application(agent, conf)
```

```
    Bases: object
```

`api_get_command(request, cmd)`

`api_list_commands(request)`

`api_root(request)`

`api_run_command(request)`

`api_status(request)`

`api_v1(request)`

`handle_exception(environ, exc)`

Handle an exception during request processing.

`start(tls_cert_file=None, tls_key_file=None)`

Start the API service in the background.

`stop()`

Stop the API service.

`class ironic_python_agent.api.app.Request`(*environ: WSGIEnvironment, populate_request: bool = True, shallow: bool = False*)

Bases: Request

Custom request class with JSON support.

`ironic_python_agent.api.app.format_exception(value)`

`ironic_python_agent.api.app.jsonify(value, status=200)`

Convert value to a JSON response using the custom encoder.

`ironic_python_agent.api.app.make_link(url, rel_name, resource="", resource_args="", bookmark=False, type_=None)`

`ironic_python_agent.api.app.version(url)`

Module contents

`ironic_python_agent.cmd` package

Submodules

`ironic_python_agent.cmd.agent` module

`ironic_python_agent.cmd.agent.run()`

Entrypoint for IronicPythonAgent.

ironic_python_agent.cmd.inspect module

`ironic_python_agent.cmd.inspect.run()`

Entrypoint for IronicPythonAgent.

Module contents

ironic_python_agent.extensions package

Submodules

ironic_python_agent.extensions.base module

class `ironic_python_agent.extensions.base.AgentCommandStatus`

Bases: `object`

Mapping of agent command statuses.

FAILED = 'FAILED'

RUNNING = 'RUNNING'

SUCCEEDED = 'SUCCEEDED'

VERSION_MISMATCH = 'CLEAN_VERSION_MISMATCH'

class `ironic_python_agent.extensions.base.AsyncCommandResult`(*command_name*,
command_params,
execute_method,
agent=None)

Bases: `BaseCommandResult`

A command that executes asynchronously in the background.

is_done()

Checks to see if command is still RUNNING.

Returns

True if command is done, False if still RUNNING

join(*timeout=None*)

Block until command has completed, and return result.

Parameters

timeout float indicating max seconds to wait for command to complete. Defaults to None.

run()

Run a command.

serialize()

Serializes the AsyncCommandResult into a dict.

Returns

dict containing serializable fields in AsyncCommandResult

start()

Begin background execution of command.

class ironic_python_agent.extensions.base.**BaseAgentExtension**(*agent=None*)

Bases: object

check_cmd_presence(*ext_obj, ext, cmd*)

execute(*command_name, **kwargs*)

class ironic_python_agent.extensions.base.**BaseCommandResult**(*command_name, command_params*)

Bases: *SerializableComparable*

Base class for command result.

is_done()

Checks to see if command is still RUNNING.

Returns

True if command is done, False if still RUNNING

join()

Returns

result of completed command.

serializable_fields = ('id', 'command_name', 'command_status', 'command_error', 'command_result')

wait()

Join the result and extract its value.

Raises if the command failed.

class ironic_python_agent.extensions.base.**ExecuteCommandMixin**

Bases: object

execute_command(*command_name, **kwargs*)

Execute an agent command.

get_extension(*extension_name*)

split_command(*command_name*)

class ironic_python_agent.extensions.base.**SyncCommandResult**(*command_name, command_params, success, result_or_error*)

Bases: *BaseCommandResult*

A result from a command that executes synchronously.

`ironic_python_agent.extensions.base.async_command(command_name, validator=None)`

Will run the command in an AsyncCommandResult in its own thread.

`command_name` is set based on the func name and `command_params` will be whatever args/kwargs you pass into the decorated command. Return values of type *str* or *unicode* are prefixed with the `command_name` parameter when returned for consistency.

`ironic_python_agent.extensions.base.get_extension(name)`

`ironic_python_agent.extensions.base.init_ext_manager(agent)`

`ironic_python_agent.extensions.base.sync_command(command_name, validator=None)`

Decorate a method to wrap its return value in a SyncCommandResult.

For consistency with `@async_command()` can also accept a validator which will be used to validate input, although a synchronous command can also choose to implement validation inline.

ironic_python_agent.extensions.clean module

`class ironic_python_agent.extensions.clean.CleanExtension(agent=None)`

Bases: *BaseAgentExtension*

`execute_clean_step(step, node, ports, clean_version=None, **kwargs)`

Execute a clean step.

Parameters

- **step** A clean step with step, priority and interface keys
- **node** A dict representation of a node
- **ports** A dict representation of ports attached to node
- **clean_version** The clean version as returned by hardware.get_current_versions() at the beginning of cleaning/zapping

Returns

a CommandResult object with `command_result` set to whatever the step returns.

`get_clean_steps(node, ports)`

Get the list of clean steps supported for the node and ports

Parameters

- **node** A dict representation of a node
- **ports** A dict representation of ports attached to node

Returns

A list of clean steps with keys step, priority, and reboot_requested

ironic_python_agent.extensions.deploy module

class `ironic_python_agent.extensions.deploy.DeployExtension(agent=None)`

Bases: *BaseAgentExtension*

execute_deploy_step(*step, node, ports, deploy_version=None, **kwargs*)

Execute a deploy step.

Parameters

- **step** A deploy step with step, priority and interface keys
- **node** A dict representation of a node
- **ports** A dict representation of ports attached to node
- **deploy_version** The deploy version as returned by hardware.get_current_versions() at the beginning of deploying.
- **kwargs** The remaining arguments are passed to the step.

Returns

A CommandResult object with command_result set to whatever the step returns.

get_deploy_steps(*node, ports*)

Get the list of deploy steps supported for the node and ports

Parameters

- **node** A dict representation of a node
- **ports** A dict representation of ports attached to node

Returns

A list of deploy steps with keys step, priority, and reboot_requested

ironic_python_agent.extensions.flow module

class `ironic_python_agent.extensions.flow.FlowExtension(agent=None)`

Bases: *BaseAgentExtension, ExecuteCommandMixin*

start_flow(*flow=None*)

ironic_python_agent.extensions.image module

class `ironic_python_agent.extensions.image.ImageExtension(agent=None)`

Bases: *BaseAgentExtension*

install_bootloader(*root_uuid, efi_system_part_uuid=None, prep_boot_part_uuid=None, target_boot_mode='bios', ignore_bootloader_failure=None*)

Install the GRUB2 bootloader on the image.

Parameters

- **root_uuid** The UUID of the root partition.

- **efi_system_part_uuid** The UUID of the efi system partition. To be used only for uefi boot mode. For uefi boot mode, the boot loader will be installed here.
- **prep_boot_part_uuid** The UUID of the PReP Boot partition. Used only for booting ppc64* partition images locally. In this scenario the bootloader will be installed here.
- **target_boot_mode** bios, uefi. Only taken into account for softraid, when no efi partition is explicitly provided (happens for whole disk images)

Raises

CommandExecutionError if the installation of the bootloader fails.

Raises

DeviceNotFound if the root partition is not found.

ironic_python_agent.extensions.log module

class `ironic_python_agent.extensions.log.LogExtension(agent=None)`

Bases: `BaseAgentExtension`

collect_system_logs()

Collect system logs.

Collect and package diagnostic and support data from the ramdisk.

Raises

CommandExecutionError if failed to collect the system logs.

Returns

A dictionary with the key `system_logs` and the value of a gzipped and base64 encoded string of the file with the logs.

ironic_python_agent.extensions.poll module

class `ironic_python_agent.extensions.poll.PollExtension(agent=None)`

Bases: `BaseAgentExtension`

get_hardware_info()

Get the hardware information where IPA is running.

set_node_info(`node_info=None`)

Set node lookup data when IPA is running at passive mode.

Parameters

node_info A dictionary contains the information of the node where IPA is running.

ironic_python_agent.extensions.rescue module

class `ironic_python_agent.extensions.rescue.RescueExtension(agent=None)`

Bases: `BaseAgentExtension`

finalize_rescue(*rescue_password=""*, *hashed=False*)

Sets the rescue password for the rescue user.

write_rescue_password(*rescue_password=""*, *hashed=False*)

Write rescue password to a file for use after IPA exits.

Parameters

- **rescue_password** Rescue password.
- **hashed** Boolean default False indicating if the password being provided is hashed or not. This will be changed in a future version of ironic.

ironic_python_agent.extensions.service module

class `ironic_python_agent.extensions.service.ServiceExtension(agent=None)`

Bases: `BaseAgentExtension`

execute_service_step(*step*, *node*, *ports*, *service_version=None*, ***kwargs*)

Execute a service step.

Parameters

- **step** A step with step, priority and interface keys
- **node** A dict representation of a node
- **ports** A dict representation of ports attached to node
- **service_version** The service version as returned by `hardware.get_current_versions()` at the beginning of the service operation.

Returns

a `CommandResult` object with `command_result` set to whatever the step returns.

get_service_steps(*node*, *ports*)

Get the list of service steps supported for the node and ports

Parameters

- **node** A dict representation of a node
- **ports** A dict representation of ports attached to node

Returns

A list of service steps with keys `step`, `priority`, and `reboot_requested`

ironic_python_agent.extensions.standby module

```
class ironic_python_agent.extensions.standby.ImageDownload(image_info,
                                                           time_obj=None)
```

Bases: object

Helper class that opens a HTTP connection to download an image.

This class opens a HTTP connection to download an image from a URL and create an iterator so the image can be downloaded in chunks. The MD5 hash of the image being downloaded is calculated on-the-fly.

property bytes_transferred

Property value to return the number of bytes transferred.

property content_length

Property value to return the server indicated length.

verify_image(image_location)

Verifies the checksum of the local images matches expectations.

If this function does not raise ImageChecksumError then it is very likely that the local copy of the image was transmitted and stored correctly.

Parameters

image_location The location of the local image.

Raises

ImageChecksumError if the checksum of the local image does not match the checksum as reported by glance in image_info.

```
class ironic_python_agent.extensions.standby.StandbyExtension(agent=None)
```

Bases: *BaseAgentExtension*

Extension which adds stand-by related functionality to agent.

get_partition_uuids()

Return partition UUIDs.

power_off()

Powers off the agents system.

prepare_image(image_info, configdrive=None)

Asynchronously prepares specified image on local OS install device.

In this case, prepare means make local machine completely ready to reboot to the image specified by image_info.

Downloads and writes an image to disk if necessary. Also writes a configdrive to disk if the configdrive parameter is specified.

Parameters

- **image_info** Image information dictionary.
- **configdrive** A string containing the location of the config drive as a URL OR the contents (as gzip/base64) of the configdrive. Optional, defaults to None.

Raises

ImageDownloadError if the image download encounters an error.

Raises

ImageChecksumError if the checksum of the local image does not match the checksum as reported by glance in image_info.

Raises

ImageWriteError if writing the image fails.

Raises

InstanceDeployFailure if failed to create config drive. large to store on the given device.

run_image()

Runs image on agents system via reboot.

sync()

Flush file system buffers forcing changed blocks to disk.

Raises

CommandExecutionError if flushing file system buffers fails.

ironic_python_agent.extensions.standby.check_md5_enabled()

Checks if md5 is permitted, otherwise raises ValueError.

Module contents

ironic_python_agent.hardware_managers package

Submodules

ironic_python_agent.hardware_managers.cna module

```
class ironic_python_agent.hardware_managers.cna.IntelCnaHardwareManager
```

Bases: *HardwareManager*

```
HARDWARE_MANAGER_NAME = 'IntelCnaHardwareManager'
```

```
HARDWARE_MANAGER_VERSION = '1.0'
```

```
evaluate_hardware_support()
```

ironic_python_agent.hardware_managers.mlnx module

```
class ironic_python_agent.hardware_managers.mlnx.MellanoxDeviceHardwareManager
```

Bases: *HardwareManager*

Mellanox hardware manager to support a single device

```
HARDWARE_MANAGER_NAME = 'MellanoxDeviceHardwareManager'
```


HARDWARE_MANAGER_VERSION = '1'

evaluate_hardware_support()

Declare level of hardware support provided.

get_clean_steps(*node*, *ports*)

Get a list of clean steps with priority.

Parameters

- **node** The node object as provided by Ironic.
- **ports** Port objects as provided by Ironic.

Returns

A list of cleaning steps, as a list of dicts.

get_deploy_steps(*node*, *ports*)

Alias wrapper for method `get_clean_steps`.

get_interface_info(*interface_name*)

Return the interface information when its Mellanox and InfiniBand

In case of Mellanox and InfiniBand interface we do the following:

1. Calculate the InfiniBand MAC according to InfiniBand GUID
2. Calculate the client-id according to InfiniBand GUID

get_service_steps(*node*, *ports*)

Alias wrapper for method `get_clean_steps`.

update_nvidia_nic_firmware_image(*node*, *ports*, *images*)

update_nvidia_nic_firmware_settings(*node*, *ports*, *settings*)

Module contents

Submodules

ironic_python_agent.agent module

class `ironic_python_agent.agent.Host`(*hostname*, *port*)

Bases: tuple

hostname

Alias for field number 0

port

Alias for field number 1

```
class ironic_python_agent.agent.IronicPythonAgent(api_url, advertise_address,  
listen_address, ip_lookup_attempts,  
ip_lookup_sleep, network_interface,  
lookup_timeout, lookup_interval,  
standalone, agent_token,  
hardware_initialization_delay=0,  
advertise_protocol='http')
```

Bases: *ExecuteCommandMixin*

Class for base agent functionality.

force_heartbeat()

get_command_result(*result_id*)

Get a specific command result by ID.

Returns

a `ironic_python_agent.extensions.base.BaseCommandResult` object.

Raises

`RequestedObjectNotFoundError` if command with the given ID is not found.

get_node_uuid()

Get UUID for Ironic node.

If the agent has not yet heartbeated to Ironic, it will not have the UUID and this will raise an exception.

Returns

A string containing the UUID for the Ironic node.

Raises

`UnknownNodeError` if UUID is unknown.

get_status()

Retrieve a serializable status.

Returns

a `ironic_python_agent.agent.IronicPythonAgent` instance describing the agents status.

list_command_results()

Get a list of command results.

Returns

list of `ironic_python_agent.extensions.base.BaseCommandResult` objects.

process_lookup_data(*content*)

Update agent configuration from lookup data.

run()

Run the Ironic Python Agent.

serve_ipa_api()

Serve the API until an extension terminates it.

set_agent_advertise_addr()

Set advertised IP address for the agent, if not already set.

If agents advertised IP address is still default (None), try to find a better one. If the agents network interface is None, replace that as well.

Raises

LookupAgentIPError if an IP address could not be found

validate_agent_token(token)**class** `ironic_python_agent.agent.IronicPythonAgentHeartbeater(agent)`

Bases: Thread

Thread that periodically heartbeats to Ironic.

do_heartbeat()

Send a heartbeat to Ironic.

force_heartbeat()

max_jitter_multiplier = 0.6

min_jitter_multiplier = 0.3

run()

Start the heartbeat thread.

stop()

Stop the heartbeat thread.

class `ironic_python_agent.agent.IronicPythonAgentStatus(started_at, version)`

Bases: *Serializable*

Represents the status of an agent.

serializable_fields = ('started_at', 'version')

ironic_python_agent.burnin module`ironic_python_agent.burnin.fio_disk(node)`

Burn-in the disks with fio

Run an fio randrw job for a configurable number of iterations or a given amount of time.

Parameters

node Ironic node object

Raises

CommandExecutionError if the execution of fio fails.

`ironic_python_agent.burnin.fio_network(node)`

Burn-in the network with fio

Run an fio network job for a pair of nodes for a configurable amount of time. The pair is either statically defined in driver_info via agent_burnin_fio_network_config or the role and partner is found dynamically via a tooz backend.

The writer will wait for the reader to connect, then write to the network. Upon completion, the roles are swapped.

Parameters

node Ironic node object

Raises

CommandExecutionError if the execution of fio fails.

Raises

CleaningError if the configuration is incomplete.

`ironic_python_agent.burnin.stress_ng_cpu(node)`

Burn-in the CPU with stress-ng

Run stress-ng on a configurable number of CPUs for a configurable amount of time. Without config use all CPUs and stress them for 24 hours.

Parameters

node Ironic node object

Raises

CommandExecutionError if the execution of stress-ng fails.

`ironic_python_agent.burnin.stress_ng_vm(node)`

Burn-in the memory with the vm stressor in stress-ng

Run stress-ng with a configurable number of workers on a configurable amount of the available memory for a configurable amount of time. Without config use as many workers as CPUs, 98% of the memory and stress it for 24 hours.

Parameters

node Ironic node object

Raises

CommandExecutionError if the execution of stress-ng fails.

`ironic_python_agent.config` module

`ironic_python_agent.config.list_opts()`

`ironic_python_agent.config.override(params)`

Override configuration with values from a dictionary.

This is used for configuration overrides from mDNS.

Parameters

params new configuration parameters as a dict.

ironic_python_agent.dmi_inspector module

`ironic_python_agent.dmi_inspector.collect_dmidecode_info(data, failures)`

Collect detailed processor, memory and bios info.

The data is gathered using dmidecode utility.

Parameters

- **data** mutable dict that will send to inspector
- **failures** AccumulatedFailures object

`ironic_python_agent.dmi_inspector.parse_dmi(data)`

Parse the dmidecode output.

Returns a dict.

ironic_python_agent.efi_utils module

`ironic_python_agent.efi_utils.add_boot_record(device, efi_partition, loader, label)`

Add an EFI boot record with efibootmgr.

Parameters

- **device** the device to be used
- **efi_partition** the number of the EFI partition on the device
- **loader** path to the EFI boot loader
- **label** the record label

`ironic_python_agent.efi_utils.get_boot_records()`

Executes efibootmgr and returns boot records.

Returns

an iterator yielding pairs (boot number, boot record).

`ironic_python_agent.efi_utils.get_partition_path_by_number(device, part_num)`

Get partition path (/dev/something) by a partition number on device.

Only works for GPT partition table.

`ironic_python_agent.efi_utils.manage_uefi(device, efi_system_part_uuid=None)`

Manage the device looking for valid efi bootloaders to update the nvram.

This method checks for valid efi bootloaders in the device, if they exist it updates the nvram using the efibootmgr.

Parameters

- **device** the device to be checked.
- **efi_system_part_uuid** efi partition uuid.

Raises

DeviceNotFound if the efi partition cannot be found.

Returns

True - if it finds any efi bootloader and the nvram was updated using the efibootmgr. False - if no efi bootloader is found.

`ironic_python_agent.efi_utils.remove_boot_record(boot_num)`

Remove an EFI boot record with efibootmgr.

Parameters

boot_num the number of the boot record

ironic_python_agent.encoding module

```
class ironic_python_agent.encoding.RESTJSONEncoder(*, skipkeys=False,
                                                    ensure_ascii=True,
                                                    check_circular=True,
                                                    allow_nan=True, sort_keys=False,
                                                    indent=None, separators=None,
                                                    default=None)
```

Bases: `JSONEncoder`

A slightly customized JSON encoder.

default(*o*)

Turn an object into a serializable object.

In particular, by calling `Serializable.serialize()` on *o*.

encode(*o*)

Turn an object into JSON.

Appends a newline to responses when configured to pretty-print, in order to make use of curl less painful from most shells.

```
class ironic_python_agent.encoding.Serializable
```

Bases: `object`

Base class for things that can be serialized.

serializable_fields = ()

serialize()

Turn this object into a dict.

```
class ironic_python_agent.encoding.SerializableComparable
```

Bases: `Serializable`

A Serializable class which supports some comparison operators

This class supports the `__eq__` and `__ne__` comparison operators, but intentionally disables the `__hash__` operator as some child classes may be mutable. The addition of these comparison operators is mainly used to assist with unit testing.

```
ironic_python_agent.encoding.serialize_lib_exc(exc)
```

Serialize an ironic-lib exception.

ironic_python_agent.errors module

exception `ironic_python_agent.errors.AgentIsBusy(command_name)`

Bases: `CommandExecutionError`

message = 'Agent is busy'

status_code = 409

exception `ironic_python_agent.errors.BlockDeviceEraseError(details)`

Bases: `RESTError`

Error raised when an error occurs erasing a block device.

message = 'Error erasing block device'

exception `ironic_python_agent.errors.BlockDeviceError(details)`

Bases: `RESTError`

Error raised when a block devices causes an unknown error.

message = 'Block device caused unknown error'

exception `ironic_python_agent.errors.CleaningError(details=None)`

Bases: `RESTError`

Error raised when a cleaning step fails.

message = 'Clean step failed'

exception `ironic_python_agent.errors.ClockSyncError(details=None, *args, **kwargs)`

Bases: `RESTError`

Error raised when attempting to sync the system clock.

message = 'Error syncing system clock'

exception `ironic_python_agent.errors.CommandExecutionError(details)`

Bases: `RESTError`

Error raised when a command fails to execute.

message = 'Command execution failed'

exception `ironic_python_agent.errors.DeploymentError(details=None)`

Bases: `RESTError`

Error raised when a deploy step fails.

message = 'Deploy step failed'

exception `ironic_python_agent.errors.DeviceNotFound(details)`

Bases: `NotFound`

Error raised when the device to deploy the image onto is not found.

message = 'Error finding the disk or partition device to deploy the image onto'

exception `ironic_python_agent.errors.ExtensionError`(*details=None, *args, **kwargs*)

Bases: [RESTError](#)

exception `ironic_python_agent.errors.HardwareManagerMethodNotFound`(*method*)

Bases: [RESTError](#)

Error raised when all HardwareManagers fail to handle a method.

message = 'No HardwareManager found to handle method'

exception `ironic_python_agent.errors.HardwareManagerNotFound`(*details=None*)

Bases: [RESTError](#)

Error raised when no valid HardwareManager can be found.

message = 'No valid HardwareManager found'

exception `ironic_python_agent.errors.HeartbeatConflictError`(*details*)

Bases: [IronicAPIError](#)

ConflictError raised when a heartbeat to the agent API fails.

message = 'ConflictError heartbeating to agent API'

exception `ironic_python_agent.errors.HeartbeatConnectionError`(*details*)

Bases: [IronicAPIError](#)

Transitory connection failure occurred attempting to contact the API.

message = 'Error attempting to heartbeat - Possible transitory network failure or blocking port may be present.'

exception `ironic_python_agent.errors.HeartbeatError`(*details*)

Bases: [IronicAPIError](#)

Error raised when a heartbeat to the agent API fails.

message = 'Error heartbeating to agent API'

exception `ironic_python_agent.errors.ImageChecksumError`(*image_id, image_location, checksum, calculated_checksum*)

Bases: [RESTError](#)

Error raised when an image fails to verify against its checksum.

details_str = 'Image failed to verify against checksum. location: {}; image ID: {}; image checksum: {}; verification checksum: {}'

message = 'Error verifying image checksum'

exception `ironic_python_agent.errors.ImageDownloadError`(*image_id, msg*)

Bases: [RESTError](#)

Error raised when an image cannot be downloaded.

message = 'Error downloading image'

exception `ironic_python_agent.errors.ImageWriteError(device, exit_code, stdout, stderr)`

Bases: [RESTError](#)

Error raised when an image cannot be written to a device.

message = 'Error writing image to device'

exception `ironic_python_agent.errors.IncompatibleHardwareMethodError(details=None)`

Bases: [RESTError](#)

Error raised when HardwareManager method incompatible with hardware.

message = 'HardwareManager method is not compatible with hardware'

exception `ironic_python_agent.errors.IncompatibleNumaFormatError(details=None, *args, **kwargs)`

Bases: [RESTError](#)

Error raised when unexpected format data in NUMA node.

message = 'Error in NUMA node data format'

exception `ironic_python_agent.errors.InspectionError`

Bases: `Exception`

Failure during inspection.

exception `ironic_python_agent.errors.InvalidCommandError(details)`

Bases: [InvalidContentError](#)

Error which is raised when an unknown command is issued.

message = 'Invalid command'

exception `ironic_python_agent.errors.InvalidCommandParamsError(details)`

Bases: [InvalidContentError](#)

Error which is raised when command parameters are invalid.

message = 'Invalid command parameters'

exception `ironic_python_agent.errors.InvalidContentError(details)`

Bases: [RESTError](#)

Error which occurs when a user supplies invalid content.

Either because that content cannot be parsed according to the advertised *Content-Type*, or due to a content validation error.

message = 'Invalid request body'

status_code = 400

exception `ironic_python_agent.errors.IronicAPIError(details)`

Bases: [RESTError](#)

Error raised when a call to the agent API fails.

message = 'Error in call to ironic-api'

exception `ironic_python_agent.errors.LookupAgentIPError`(*details*)

Bases: *IronicAPIError*

Error raised when automatic IP lookup fails.

message = 'Error finding IP for Ironic Agent'

exception `ironic_python_agent.errors.LookupNodeError`(*details*)

Bases: *IronicAPIError*

Error raised when the node lookup to the Ironic API fails.

message = 'Error getting configuration from Ironic'

exception `ironic_python_agent.errors.NotFound`(*details=None, *args, **kwargs*)

Bases: *RESTError*

Error which occurs if a non-existent API endpoint is called.

details = 'The requested URL was not found.'

message = 'Not found'

status_code = 404

exception `ironic_python_agent.errors.ProtectedDeviceError`(*device, what*)

Bases: *CleaningError*

Error raised when a cleaning is halted due to a protected device.

message = 'Protected device located, cleaning aborted.'

exception `ironic_python_agent.errors.RESTError`(*details=None, *args, **kwargs*)

Bases: *Exception, Serializable*

Base class for errors generated in ironic-python-client.

details = 'An unexpected error occurred. Please try back later.'

message = 'An error occurred'

serializable_fields = ('type', 'code', 'message', 'details')

status_code = 500

exception `ironic_python_agent.errors.RequestedObjectNotFoundError`(*type_descr, obj_id*)

Bases: *NotFound*

exception `ironic_python_agent.errors.ServicingError`(*details=None*)

Bases: *RESTError*

Error raised when a service step fails.

message = 'Service step failed'

exception `ironic_python_agent.errors.SoftwareRAIDError`(*details*)

Bases: *RESTError*

Error raised when a Software RAID causes an error.

```
message = 'Software RAID caused unknown error'
```

```
exception ironic_python_agent.errors.SystemRebootError(exit_code, stdout, stderr)
```

Bases: *RESTError*

Error raised when a system cannot reboot.

```
message = 'Error rebooting system'
```

```
exception ironic_python_agent.errors.UnknownNodeError(details=None)
```

Bases: *RESTError*

Error raised when the agent is not associated with an Ironic node.

```
message = 'Agent is not associated with an Ironic node'
```

```
exception ironic_python_agent.errors.VersionMismatch(agent_version, node_version)
```

Bases: *RESTError*

Error raised when Ironic and the Agent have different versions.

If the agent version has changed since `get_clean_steps` or `get_deploy_steps` was called by the Ironic conductor, it indicates the agent has been updated (either on purpose, or a new agent was deployed and the node was rebooted). Since we cannot know if the upgraded IPA will work with cleaning/deploy as it stands (steps could have different priorities, either in IPA or in other Ironic interfaces), we should restart the process from the start.

```
message = 'Hardware managers version mismatch, reload agent with correct version'
```

```
exception ironic_python_agent.errors.VirtualMediaBootError(details)
```

Bases: *RESTError*

Error raised when virtual media device cannot be found for config.

```
message = 'Configuring agent from virtual media failed'
```

`ironic_python_agent.hardware` module

```
class ironic_python_agent.hardware.BlockDevice(name, model, size, rotational,
                                                wwn=None, serial=None, vendor=None,
                                                wwn_with_extension=None,
                                                wwn_vendor_extension=None,
                                                hctl=None, by_path=None, uuid=None,
                                                partuuid=None)
```

Bases: *SerializableComparable*

```
serializable_fields = ('name', 'model', 'size', 'rotational', 'wwn',
                        'serial', 'vendor', 'wwn_with_extension', 'wwn_vendor_extension', 'hctl',
                        'by_path')
```

```
class ironic_python_agent.hardware.BootInfo(current_boot_mode, pxe_interface=None)
```

Bases: *SerializableComparable*

```
serializable_fields = ('current_boot_mode', 'pxe_interface')
```

```
class ironic_python_agent.hardware.CPU(model_name, frequency, count, architecture,  
                                       flags=None)
```

Bases: *SerializableComparable*

```
serializable_fields = ('model_name', 'frequency', 'count', 'architecture',  
                       'flags')
```

```
class ironic_python_agent.hardware.GenericHardwareManager
```

Bases: *HardwareManager*

```
HARDWARE_MANAGER_NAME = 'generic_hardware_manager'
```

```
HARDWARE_MANAGER_VERSION = '1.2'
```

```
apply_configuration(node, ports, raid_config, delete_existing=True)
```

Apply RAID configuration.

Parameters

- **node** A dictionary of the node object.
- **ports** A list of dictionaries containing information of ports for the node.
- **raid_config** The configuration to apply.
- **delete_existing** Whether to delete the existing configuration.

```
burnin_cpu(node, ports)
```

Burn-in the CPU

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

```
burnin_disk(node, ports)
```

Burn-in the disk

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

```
burnin_memory(node, ports)
```

Burn-in the memory

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

```
burnin_network(node, ports)
```

Burn-in the network

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

collect_lldp_data(*interface_names=None*)

Collect and convert LLDP info from the node.

In order to process the LLDP information later, the raw data needs to be converted for serialization purposes.

Parameters

interface_names list of names of nodes interfaces.

Returns

a dict, containing the lldp data from every interface.

collect_system_logs(*io_dict, file_list*)

Collect logs from the system.

Implementations should update *io_dict* and *file_list* with logs to send to Ironic and Inspector.

Parameters

- **io_dict** Dictionary mapping file names to binary IO objects with corresponding data.
- **file_list** List of full file paths to include.

create_configuration(*node, ports*)

Create a RAID configuration.

Unless overwritten by a local hardware manager, this method will create a software RAID configuration as read from the nodes *target_raid_config*.

Parameters

- **node** A dictionary of the node object.
- **ports** A list of dictionaries containing information of ports for the node.

Returns

The current RAID configuration in the usual format.

Raises

SoftwareRAIDError if the desired configuration is not valid or if there was an error when creating the RAID devices.

delete_configuration(*node, ports*)

Delete a RAID configuration.

Unless overwritten by a local hardware manager, this method will delete all software RAID devices on the node. NOTE(arne_wiebalck): It may be worth considering to only delete RAID devices in the nodes *target_raid_config*. If that config has been lost, though, the cleanup may become difficult. So, for now, we delete everything we detect.

Parameters

- **node** A dictionary of the node object
- **ports** A list of dictionaries containing information of ports for the node

erase_block_device(*node, block_device*)

Attempt to erase a block device.

Implementations should detect the type of device and erase it in the most appropriate way possible. Generic implementations should support common erase mechanisms such as ATA secure erase, or multi-pass random writes. Operators with more specific needs should override this method in order to detect and handle interesting cases, or delegate to the parent class to handle generic cases.

For example: operators running ACME MagicStore (TM) cards alongside standard SSDs might check whether the device is a MagicStore and use a proprietary tool to erase that, otherwise call this method on their parent class. Upstream submissions of common functionality are encouraged.

This interface could be called concurrently to speed up erasure, as such, it should be implemented in a thread-safe way.

Parameters

- **node** Ironic node object
- **block_device** a BlockDevice indicating a device to be erased.

Raises

- *IncompatibleHardwareMethodError* when there is no known way to erase the block device
- *BlockDeviceEraseError* when there is an error erasing the block device

erase_devices_express(*node, ports*)

Attempt to perform time-optimised disk erasure:

for NVMe devices, perform NVMe Secure Erase if supported. For other devices, perform metadata erasure

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

Raises

BlockDeviceEraseError when theres an error erasing the block device

Raises

ProtectedDeviceFound if a device has been identified which may require manual intervention due to the contents and operational risk which exists as it could also be a sign of an environmental misconfiguration.

erase_devices_metadata(*node, ports*)

Attempt to erase the disk devices metadata.

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

Raises

BlockDeviceEraseError when theres an error erasing the block device

Raises

ProtectedDeviceFound if a device has been identified which may require manual intervention due to the contents and operational risk which exists as it could also be a sign of an environmental misconfiguration.

erase_pstore(*node, ports*)

Attempt to erase the kernel pstore.

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

evaluate_hardware_support()

generate_tls_certificate(*ip_address*)

Generate a TLS certificate for the IP address.

get_bios_given_nic_name(*interface_name*)

Collect the BIOS given NICs name.

This function uses the biosdevname utility to collect the BIOS given name of network interfaces.

The collected data is added to the network interface inventory with an extra field named biosdevname.

Parameters

interface_name list of names of nodes interfaces.

Returns

the BIOS given NIC name of nodes interfaces or default as None.

get_bmc_address()

Attempt to detect BMC IP address

Returns

IP address of lan channel or 0.0.0.0 in case none of them is configured properly

get_bmc_mac()

Attempt to detect BMC MAC address

Returns

MAC address of the first LAN channel or 00:00:00:00:00:00 in case none of them has one or is configured properly

get_bmc_v6address()

Attempt to detect BMC v6 address

Returns

IPv6 address of lan channel or ::/0 in case none of them is configured properly. May return None value if it cannot interact with system tools or critical error occurs.

get_boot_info()

`get_clean_steps(node, ports)`

Get a list of clean steps with priority.

Returns a list of steps. Each step is represented by a dict:

```
{
  'interface': the name of the driver interface that should execute
               the step.
  'step': the HardwareManager function to call.
  'priority': the order steps will be run in. Ironic will sort all
               the clean steps from all the drivers, with the largest
               priority step being run first. If priority is set to 0,
               the step will not be run during cleaning, but may be
               run during zapping.
  'reboot_requested': Whether the agent should request Ironic reboots
                     the node via the power driver after the
                     operation completes.
  'abortable': Boolean value. Whether the clean step can be
               stopped by the operator or not. Some clean step may
               cause non-reversible damage to a machine if interrupted
               (i.e firmware update), for such steps this parameter
               should be set to False. If no value is set for this
               parameter, Ironic will consider False (non-abortable).
}
```

If multiple hardware managers return the same step name, the following logic will be used to determine which managers step wins:

- Keep the step that belongs to HardwareManager with highest HardwareSupport (larger int) value.
- If equal support level, keep the step with the higher defined priority (larger int).
- If equal support level and priority, keep the step associated with the HardwareManager whose name comes earlier in the alphabet.

The steps will be called using `hardware.dispatch_to_managers` and handled by the best suited hardware manager. If you need a step to be executed by only your hardware manager, ensure it has a unique step name.

`node` and `ports` can be used by other hardware managers to further determine if a clean step is supported for the node.

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

Returns

a list of cleaning steps, where each step is described as a dict as defined above

`get_cpus()`

`get_deploy_steps(node, ports)`

Get a list of deploy steps with priority.

Returns a list of steps. Each step is represented by a dict:


```
{
  'interface': the name of the driver interface that should execute
               the step.
  'step': the HardwareManager function to call.
  'priority': the order steps will be run in. Ironic will sort all
               the deploy steps from all the drivers, with the largest
               priority step being run first. If priority is set to 0,
               the step will not be run during deployment
               automatically, but may be requested via deploy
               templates.
  'reboot_requested': Whether the agent should request Ironic reboots
                       the node via the power driver after the
                       operation completes.
  'argsinfo': arguments specification.
}
```

If multiple hardware managers return the same step name, the following logic will be used to determine which managers step wins:

- Keep the step that belongs to HardwareManager with highest HardwareSupport (larger int) value.
- If equal support level, keep the step with the higher defined priority (larger int).
- If equal support level and priority, keep the step associated with the HardwareManager whose name comes earlier in the alphabet.

The steps will be called using `hardware.dispatch_to_managers` and handled by the best suited hardware manager. If you need a step to be executed by only your hardware manager, ensure it has a unique step name.

`node` and `ports` can be used by other hardware managers to further determine if a deploy step is supported for the node.

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

Returns

a list of deploying steps, where each step is described as a dict as defined above

get_interface_info(*interface_name*)

get_ipv4_addr(*interface_id*)

get_ipv6_addr(*interface_id*)

Get the default IPv6 address assigned to the interface.

With different networking environment, the address could be a link-local address, ULA or something else.

get_memory()

get_os_install_device(*permit_refresh=False*)

`get_service_steps(node, ports)`

Get a list of service steps.

Returns a list of steps. Each step is represented by a dict:

```
{
  'interface': the name of the driver interface that should execute
               the step.
  'step': the HardwareManager function to call.
  'priority': the order steps will be run in if excuted upon
               similar to automated cleaning or deployment.
               In service steps, the order comes from the user request,
               but this similarity is kept for consistency should we
               further extend the capability at some point in the
               future.
  'reboot_requested': Whether the agent should request Ironic reboots
                     the node via the power driver after the
                     operation completes.
  'abortable': Boolean value. Whether the service step can be
               stopped by the operator or not. Some steps may
               cause non-reversible damage to a machine if interrupted
               (i.e firmware update), for such steps this parameter
               should be set to False. If no value is set for this
               parameter, Ironic will consider False (non-abortable).
}
```

If multiple hardware managers return the same step name, the following logic will be used to determine which managers step wins:

- Keep the step that belongs to HardwareManager with highest HardwareSupport (larger int) value.
- If equal support level, keep the step with the higher defined priority (larger int).
- If equal support level and priority, keep the step associated with the HardwareManager whose name comes earlier in the alphabet.

The steps will be called using `hardware.dispatch_to_managers` and handled by the best suited hardware manager. If you need a step to be executed by only your hardware manager, ensure it has a unique step name.

`node` and `ports` can be used by other hardware managers to further determine if a step is supported for the node.

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

Returns

a list of service steps, where each step is described as a dict as defined above

`get_skip_list_from_node(node, block_devices=None, just_raids=False)`

Get the skip block devices list from the node

Parameters

- **block_devices** a list of BlockDevices
- **just_raids** a boolean to signify that only RAID devices are important

Returns

A set of names of devices on the skip list

get_system_vendor_info()

inject_files(*node, ports, files=None, verify_ca=True*)

A deploy step to inject arbitrary files.

Parameters

- **node** A dictionary of the node object
- **ports** A list of dictionaries containing information of ports for the node (unused)
- **files** See `inject_files`
- **verify_ca** Whether to verify TLS certificate.

list_block_devices(*include_partitions=False*)

List physical block devices

Parameters

include_partitions If to include partitions

Returns

A list of BlockDevices

list_block_devices_check_skip_list(*node, include_partitions=False*)

List physical block devices without the ones listed in
properties/skip_block_devices list

Parameters

- **node** A node used to check the skip list
- **include_partitions** If to include partitions

Returns

A list of BlockDevices

list_hardware_info()

Return full hardware inventory as a serializable dict.

This inventory is sent to Ironic on lookup and to Inspector on inspection.

Returns

a dictionary representing inventory

list_network_interfaces()

validate_configuration(*raid_config, node*)

Validate a (software) RAID configuration

Validate a given `raid_config`, in particular with respect to the limitations of the current implementation of software RAID support.

Parameters

raid_config The current RAID configuration in the usual format.

write_image(*node, ports, image_info, configdrive=None*)

A deploy step to write an image.

Downloads and writes an image to disk if necessary. Also writes a configdrive to disk if the configdrive parameter is specified.

Parameters

- **node** A dictionary of the node object
- **ports** A list of dictionaries containing information of ports for the node
- **image_info** Image information dictionary.
- **configdrive** A string containing the location of the config drive as a URL OR the contents (as gzip/base64) of the configdrive. Optional, defaults to None.

class `ironic_python_agent.hardware.HardwareManager`

Bases: `object`

collect_lldp_data(*interface_names=None*)

collect_system_logs(*io_dict, file_list*)

Collect logs from the system.

Implementations should update *io_dict* and *file_list* with logs to send to Ironic and Inspector.

Parameters

- **io_dict** Dictionary mapping file names to binary IO objects with corresponding data.
- **file_list** List of full file paths to include.

erase_block_device(*node, block_device*)

Attempt to erase a block device.

Implementations should detect the type of device and erase it in the most appropriate way possible. Generic implementations should support common erase mechanisms such as ATA secure erase, or multi-pass random writes. Operators with more specific needs should override this method in order to detect and handle interesting cases, or delegate to the parent class to handle generic cases.

For example: operators running ACME MagicStore (TM) cards alongside standard SSDs might check whether the device is a MagicStore and use a proprietary tool to erase that, otherwise call this method on their parent class. Upstream submissions of common functionality are encouraged.

This interface could be called concurrently to speed up erasure, as such, it should be implemented in a thread-safe way.

Parameters

- **node** Ironic node object
- **block_device** a `BlockDevice` indicating a device to be erased.

Raises

- ***IncompatibleHardwareMethodError*** when there is no known way to erase the block device
- ***BlockDeviceEraseError*** when there is an error erasing the block device

erase_devices(*node, ports*)

Erase any device that holds user data.

By default this will attempt to erase block devices. This method can be overridden in an implementation-specific hardware manager in order to erase additional hardware, although backwards-compatible upstream submissions are encouraged.

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

Raises

ProtectedDeviceFound if a device has been identified which may require manual intervention due to the contents and operational risk which exists as it could also be a sign of an environmental misconfiguration.

Returns

a dictionary in the form {device.name: erasure output}

abstract evaluate_hardware_support()**generate_tls_certificate**(*ip_address*)**get_bmc_address**()**get_bmc_mac**()**get_bmc_v6address**()**get_boot_info**()**get_clean_steps**(*node, ports*)

Get a list of clean steps with priority.

Returns a list of steps. Each step is represented by a dict:

```
{
  'interface': the name of the driver interface that should execute
               the step.
  'step': the HardwareManager function to call.
  'priority': the order steps will be run in. Ironic will sort all
               the clean steps from all the drivers, with the largest
               priority step being run first. If priority is set to 0,
               the step will not be run during cleaning, but may be
               run during zapping.
  'reboot_requested': Whether the agent should request Ironic reboots
                       the node via the power driver after the
                       operation completes.
  'abortable': Boolean value. Whether the clean step can be
```

(continues on next page)

(continued from previous page)

```

stopped by the operator or not. Some clean step may
cause non-reversible damage to a machine if interrupted
(i.e firmware update), for such steps this parameter
should be set to False. If no value is set for this
parameter, Ironic will consider False (non-abortable).
}

```

If multiple hardware managers return the same step name, the following logic will be used to determine which managers step wins:

- Keep the step that belongs to HardwareManager with highest HardwareSupport (larger int) value.
- If equal support level, keep the step with the higher defined priority (larger int).
- If equal support level and priority, keep the step associated with the HardwareManager whose name comes earlier in the alphabet.

The steps will be called using *hardware.dispatch_to_managers* and handled by the best suited hardware manager. If you need a step to be executed by only your hardware manager, ensure it has a unique step name.

node and *ports* can be used by other hardware managers to further determine if a clean step is supported for the node.

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

Returns

a list of cleaning steps, where each step is described as a dict as defined above

`get_cpus()`

`get_deploy_steps(node, ports)`

Get a list of deploy steps with priority.

Returns a list of steps. Each step is represented by a dict:

```

{
  'interface': the name of the driver interface that should execute
               the step.
  'step': the HardwareManager function to call.
  'priority': the order steps will be run in. Ironic will sort all
               the deploy steps from all the drivers, with the largest
               priority step being run first. If priority is set to 0,
               the step will not be run during deployment
               automatically, but may be requested via deploy
               templates.
  'reboot_requested': Whether the agent should request Ironic reboots
                       the node via the power driver after the
                       operation completes.
}

```

(continues on next page)

(continued from previous page)

```
'argsinfo': arguments specification.
}
```

If multiple hardware managers return the same step name, the following logic will be used to determine which managers step wins:

- Keep the step that belongs to HardwareManager with highest HardwareSupport (larger int) value.
- If equal support level, keep the step with the higher defined priority (larger int).
- If equal support level and priority, keep the step associated with the HardwareManager whose name comes earlier in the alphabet.

The steps will be called using *hardware.dispatch_to_managers* and handled by the best suited hardware manager. If you need a step to be executed by only your hardware manager, ensure it has a unique step name.

node and *ports* can be used by other hardware managers to further determine if a deploy step is supported for the node.

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

Returns

a list of deploying steps, where each step is described as a dict as defined above

get_interface_info(*interface_name*)

get_memory()

get_os_install_device(*permit_refresh=False*)

get_service_steps(*node, ports*)

Get a list of service steps.

Returns a list of steps. Each step is represented by a dict:

```
{
  'interface': the name of the driver interface that should execute
               the step.
  'step': the HardwareManager function to call.
  'priority': the order steps will be run in if excuted upon
               similar to automated cleaning or deployment.
               In service steps, the order comes from the user request,
               but this similarity is kept for consistency should we
               further extend the capability at some point in the
               future.
  'reboot_requested': Whether the agent should request Ironic reboots
                       the node via the power driver after the
                       operation completes.
  'abortable': Boolean value. Whether the service step can be
                stopped by the operator or not. Some steps may
```

(continues on next page)

(continued from previous page)

```
cause non-reversible damage to a machine if interrupted
(i.e firmware update), for such steps this parameter
should be set to False. If no value is set for this
parameter, Ironic will consider False (non-abortable).
```

}

If multiple hardware managers return the same step name, the following logic will be used to determine which managers step wins:

- Keep the step that belongs to HardwareManager with highest HardwareSupport (larger int) value.
- If equal support level, keep the step with the higher defined priority (larger int).
- If equal support level and priority, keep the step associated with the HardwareManager whose name comes earlier in the alphabet.

The steps will be called using *hardware.dispatch_to_managers* and handled by the best suited hardware manager. If you need a step to be executed by only your hardware manager, ensure it has a unique step name.

node and *ports* can be used by other hardware managers to further determine if a step is supported for the node.

Parameters

- **node** Ironic node object
- **ports** list of Ironic port objects

Returns

a list of service steps, where each step is described as a dict as defined above

get_skip_list_from_node(*node*, *block_devices=None*, *just_raids=False*)

Get the skip block devices list from the node

Parameters

- **block_devices** a list of BlockDevices
- **just_raids** a boolean to signify that only RAID devices are important

Returns

A set of names of devices on the skip list

get_version()

Get a name and version for this hardware manager.

In order to avoid errors and make agent upgrades painless, cleaning will check the version of all hardware managers during *get_clean_steps* at the beginning of cleaning and before executing each step in the agent.

The agent isnt aware of the steps being taken before or after via out of band steps, so it can never know if a new step is safe to run. Therefore, we default to restarting the whole process.

Returns

a dictionary with two keys: *name* and *version*, where *name* is a string identifying the hardware manager and *version* is an arbitrary version string. *name*

will be a class variable called `HARDWARE_MANAGER_NAME`, or default to the class name and `version` will be a class variable called `HARDWARE_MANAGER_VERSION` or default to 1.0.

list_block_devices(*include_partitions=False*)

List physical block devices

Parameters

include_partitions If to include partitions

Returns

A list of BlockDevices

list_block_devices_check_skip_list(*node, include_partitions=False*)

List physical block devices without the ones listed in

properties/skip_block_devices list

Parameters

- **node** A node used to check the skip list
- **include_partitions** If to include partitions

Returns

A list of BlockDevices

list_hardware_info()

Return full hardware inventory as a serializable dict.

This inventory is sent to Ironic on lookup and to Inspector on inspection.

Returns

a dictionary representing inventory

list_network_interfaces()

wait_for_disks()

Wait for the root disk to appear.

Wait for at least one suitable disk to show up or a specific disk if any device hint is specified. Otherwise neither inspection nor deployment have any chances to succeed.

class `ironic_python_agent.hardware.HardwareSupport`

Bases: `object`

Example priorities for hardware managers.

Priorities for `HardwareManagers` are integers, where largest means most specific and smallest means most generic. These values are guidelines that suggest values that might be returned by calls to `evaluate_hardware_support()`. No `HardwareManager` in mainline IPA will ever return a value greater than `MAINLINE`. Third party hardware managers should feel free to return values of `SERVICE_PROVIDER` or greater to distinguish between additional levels of hardware support.

GENERIC = 1

MAINLINE = 2

NONE = 0

```
SERVICE_PROVIDER = 3
```

```
class ironic_python_agent.hardware.HardwareType
```

```
Bases: object
```

```
MAC_ADDRESS = 'mac_address'
```

```
class ironic_python_agent.hardware.Memory(total, physical_mb=None)
```

```
Bases: SerializableComparable
```

```
serializable_fields = ('total', 'physical_mb')
```

```
class ironic_python_agent.hardware.NetworkInterface(name, mac_addr,
                                                    ipv4_address=None,
                                                    ipv6_address=None,
                                                    has_carrier=True, lldp=None,
                                                    vendor=None, product=None,
                                                    client_id=None,
                                                    biosdevname=None,
                                                    speed_mbps=None)
```

```
Bases: SerializableComparable
```

```
serializable_fields = ('name', 'mac_address', 'ipv4_address',
                       'ipv6_address', 'has_carrier', 'lldp', 'vendor', 'product', 'client_id',
                       'biosdevname', 'speed_mbps')
```

```
class ironic_python_agent.hardware.SystemFirmware(vendor, version, build_date)
```

```
Bases: SerializableComparable
```

```
serializable_fields = ('vendor', 'version', 'build_date')
```

```
class ironic_python_agent.hardware.SystemVendorInfo(product_name, serial_number,
                                                    manufacturer, firmware)
```

```
Bases: SerializableComparable
```

```
serializable_fields = ('product_name', 'serial_number', 'manufacturer',
                       'firmware')
```

```
ironic_python_agent.hardware.cache_node(node)
```

Store the node object in the hardware module.

Stores the node object in the hardware module to facilitate the access of a node information in the hardware extensions.

If the new node does not match the previously cached one, wait for the expected root device to appear.

Parameters

node Ironic node object

```
ironic_python_agent.hardware.check_versions(provided_version=None)
```

Ensure the version of hardware managers hasnt changed.

Parameters

provided_version Hardware manager versions used by ironic.

Raises

errors.VersionMismatch if any hardware manager version on the currently running agent doesnt match the one stored in provided_version.

Returns

None

`ironic_python_agent.hardware.deduplicate_steps(candidate_steps)`

Remove duplicated clean or deploy steps

Deduplicates steps returned from HardwareManagers to prevent running a given step more than once. Other than individual step priority, it doesnt actually impact the deployment which specific steps are kept and what HardwareManager they are associated with. However, in order to make testing easier, this method returns deterministic results.

Uses the following filtering logic to decide which step wins:

- Keep the step that belongs to HardwareManager with highest HardwareSupport (larger int) value.
- If equal support level, keep the step with the higher defined priority (larger int).
- If equal support level and priority, keep the step associated with the HardwareManager whose name comes earlier in the alphabet.

Parameters

candidate_steps A dict containing all possible steps from all managers, key=manager, value=list of steps

Returns

A deduplicated dictionary of {hardware_manager: [steps]}

`ironic_python_agent.hardware.dispatch_to_all_managers(method, *args, **kwargs)`

Dispatch a method to all hardware managers.

Dispatches the given method in priority order as sorted by *get_managers*. If the method doesnt exist or raises IncompatibleHardwareMethodError, it continues to the next hardware manager. All managers that have hardware support for this node will be called, and their responses will be added to a dictionary of the form {HardwareManagerClassName: response}.

Parameters

- **method** hardware manager method to dispatch
- **args** arguments to dispatched method
- **kwargs** keyword arguments to dispatched method

Raises

errors.HardwareManagerMethodNotFound if all managers raise IncompatibleHardwareMethodError.

Returns

a dictionary with keys for each hardware manager that returns a response and the value as a list of results from that hardware manager.

`ironic_python_agent.hardware.dispatch_to_managers`(*method*, **args*, ***kwargs*)

Dispatch a method to best suited hardware manager.

Dispatches the given method in priority order as sorted by *get_managers*. If the method doesn't exist or raises `IncompatibleHardwareMethodError`, it is attempted again with a more generic hardware manager. This continues until a method executes that returns any result without raising an `IncompatibleHardwareMethodError`.

Parameters

- **method** hardware manager method to dispatch
- **args** arguments to dispatched method
- **kwargs** keyword arguments to dispatched method

Returns

result of successful dispatch of method

Raises

- `HardwareManagerMethodNotFound` if all managers failed the method
- `HardwareManagerNotFound` if no valid hardware managers found

`ironic_python_agent.hardware.get_cached_node`()

Guard function around the module variable `NODE`.

`ironic_python_agent.hardware.get_component_devices`(*raid_device*)

Get the component devices of a Software RAID device.

Get the UUID of the md device and scan all other devices for the same md UUID.

Parameters

raid_device A Software RAID block device name.

Returns

A list of the component devices.

`ironic_python_agent.hardware.get_current_versions`()

Fetches versions from all hardware managers.

Returns

Dict in the format {name: version} containing one entry for every hardware manager.

`ironic_python_agent.hardware.get_holder_disks`(*raid_device*)

Get the holder disks of a Software RAID device.

Examine an md device and return its underlying disks.

Parameters

raid_device A Software RAID block device name.

Returns

A list of the holder disks.

`ironic_python_agent.hardware.get_managers`()

Get a list of hardware managers in priority order.

Use stevedore to find all eligible hardware managers, sort them based on self-reported (via `evaluate_hardware_support()`) priorities, and return them in a list. The resulting list is cached in `_global_managers`.

Returns

Priority-sorted list of hardware managers

Raises

HardwareManagerNotFound if no valid hardware managers found

`ironic_python_agent.hardware.get_multipath_status()`

Return the status of multipath initialization.

`ironic_python_agent.hardware.is_md_device(raid_device)`

Check if a device is an md device

Check if a device is a Software RAID (md) device.

Parameters

raid_device A Software RAID block device name.

Returns

True if the device is an md device, False otherwise.

`ironic_python_agent.hardware.list_all_block_devices(block_type='disk',
ignore_raid=False,
ignore_floppy=True,
ignore_empty=True,
ignore_multipath=False)`

List all physical block devices

The switches we use for `lsblk`: P for KEY=value output, b for size output in bytes, i to ensure ascii characters only, and o to specify the fields/columns we need.

Broken out as its own function to facilitate custom hardware managers that dont need to subclass `GenericHardwareManager`.

Parameters

- **block_type** Type of block device to find
- **ignore_raid** Ignore auto-identified raid devices, example: md0 Defaults to false as these are generally disk devices and should be treated as such if encountered.
- **ignore_floppy** Ignore floppy disk devices in the block device list. By default, these devices are filtered out.
- **ignore_empty** Whether to ignore disks with size equal 0.
- **ignore_multipath** Whether to ignore devices backing multipath devices. Default is to consider multipath devices, if possible.

Returns

A list of `BlockDevices`

`ironic_python_agent.hardware.list_hardware_info(use_cache=True)`

List hardware information with caching.

`ironic_python_agent.hardware.md_get_raid_devices()`

Get all discovered Software RAID (md) devices

Returns

A python dict containing details about the discovered RAID devices

`ironic_python_agent.hardware.md_restart(raid_device)`

Restart an md device

Stop and re-assemble a Software RAID (md) device.

Parameters

raid_device A Software RAID block device name.

Raises

CommandExecutionError in case the restart fails.

`ironic_python_agent.hardware.safety_check_block_device(node, device)`

Performs safety checking of a block device before destroying.

In order to guard against destruction of file systems such as shared-disk file systems (https://en.wikipedia.org/wiki/Clustered_file_system#SHARED-DISK) or similar filesystems where multiple distinct computers may have unlocked concurrent IO access to the entire block device or SAN Logical Unit Number, we need to evaluate, and block cleaning from occurring on these filesystems *unless* we have been explicitly configured to do so.

This is because cleaning is an intentionally destructive operation, and once started against such a device, given the complexities of shared disk clustered filesystems where concurrent access is a design element, in all likelihood the entire cluster can be negatively impacted, and an operator will be forced to recover from snapshot and or backups of the volumes contents.

Parameters

- **node** A node, or cached node object.
- **device** String representing the path to the block device to be checked.

Raises

ProtectedDeviceError when a device is identified with one of these known clustered filesystems, and the overall settings have not indicated for the agent to skip such safety checks.

`ironic_python_agent.hardware.save_api_client(client=None, timeout=None, interval=None)`

Preserves access to the API client for potential later re-use.

`ironic_python_agent.hardware.update_cached_node()`

Attempts to update the node cache via the API

ironic_python_agent.inject_files module

Implementation of the inject_files deploy step.

`ironic_python_agent.inject_files.find_partition_with_path(path, device=None)`

Find a partition with the given path.

Parameters

- **path** Expected path.
- **device** Target device. If None, the root device is used.

Returns

A context manager that will unmount and delete the temporary mount point on exit.

`ironic_python_agent.inject_files.inject_files(node, ports, files, verify_ca=True)`

A deploy step to inject arbitrary files.

Parameters

- **node** A dictionary of the node object
- **ports** A list of dictionaries containing information of ports for the node
- **files** See ARGSINFO.
- **verify_ca** Whether to verify TLS certificate.

Raises

InvalidCommandParamsError

ironic_python_agent.inspect module

`class ironic_python_agent.inspect.IronicInspection`

Bases: Thread

Class for manual inspection functionality.

`backoff_factor = 2.7`

`max_delay = 1200`

`max_jitter_multiplier = 1.2`

`min_jitter_multiplier = 0.7`

`run()`

Run Inspection.

`ironic_python_agent.inspector` module

`ironic_python_agent.inspector.call_inspector(data, failures)`

Post data to inspector.

`ironic_python_agent.inspector.collect_default(data, failures)`

The default inspection collector.

This is the only collector that is called by default. It collects the whole inventory as returned by the hardware manager(s).

It also tries to get BMC address, PXE boot device and the expected root device.

Parameters

- **data** mutable data that well send to inspector
- **failures** AccumulatedFailures object

`ironic_python_agent.inspector.collect_extra_hardware(data, failures)`

Collect detailed inventory using hardware-detect utility.

Recognizes ipa-inspection-benchmarks with list of benchmarks (possible values are cpu, disk, mem) to run. No benchmarks are run by default, as theyre pretty time-consuming.

Puts collected data as JSON under data key. Requires hardware python package to be installed on the ramdisk in addition to the packages in requirements.txt.

Parameters

- **data** mutable data that well send to inspector
- **failures** AccumulatedFailures object

`ironic_python_agent.inspector.collect_lldp(data, failures)`

Collect LLDP information for network interfaces.

Parameters

- **data** mutable data that well send to inspector
- **failures** AccumulatedFailures object

`ironic_python_agent.inspector.collect_logs(data, failures)`

Collect system logs from the ramdisk.

As inspection runs before any nodes details are known, its handy to have logs returned with data. This collector sends logs to inspector in format expected by the ramdisk_error plugin: base64 encoded tar.gz.

This collector should be installed last in the collector chain, otherwise it wont collect enough logs.

This collector does not report failures.

Parameters

- **data** mutable data that well send to inspector
- **failures** AccumulatedFailures object

`ironic_python_agent.inspector.collect_pci_devices_info(data, failures)`

Collect a list of PCI devices.

Each PCI device entry in list is a dictionary containing `vendor_id` and `product_id` keys, which will be then used by the ironic inspector to distinguish various PCI devices.

The data is gathered from `/sys/bus/pci/devices` directory.

Parameters

- **data** mutable data that well send to inspector
- **failures** AccumulatedFailures object

`ironic_python_agent.inspector.extension_manager(names)`

`ironic_python_agent.inspector.inspect()`

Optionally run inspection on the current node.

If `inspection_callback_url` is set in the configuration, get the hardware inventory from the node and post it back to the inspector.

Returns

node UUID if inspection was successful, None if associated node was not found in inspector cache. None is also returned if inspector support is not enabled.

`ironic_python_agent.inspector.wait_for_dhcp()`

Wait until NICs get their IP addresses via DHCP or timeout happens.

Depending on the value of `inspection_dhcp_all_interfaces` configuration option will wait for either all or only PXE booting NIC.

Note: only supports IPv4 addresses for now.

Returns

True if all NICs got IP addresses, False if timeout happened. Also returns True if waiting is disabled via configuration.

ironic_python_agent.ironic_api_client module

`class ironic_python_agent.ironic_api_client.APIClient(api_url)`

Bases: object

`agent_token = None`

`api_version = 'v1'`

`heartbeat(uuid, advertise_address, advertise_protocol='http', generated_cert=None)`

`heartbeat_api = '/v1/heartbeat/{uuid}'`

`lookup_api = '/v1/lookup'`

`lookup_lock_pause = 0`

`lookup_node(hardware_info, timeout, starting_interval, node_uuid=None, max_interval=60)`

`supports_auto_tls()`

ironic_python_agent.netutils module

class `ironic_python_agent.netutils.RawPromiscuousSockets`(*interface_names, protocol*)

Bases: `object`

`ironic_python_agent.netutils.bring_up_vlan_interfaces`(*interfaces_list*)

Bring up vlan interfaces based on kernel params

Use the configured value of `enable_vlan_interfaces` to determine if VLAN interfaces should be brought up using `ip` commands. If `enable_vlan_interfaces` defines a particular vlan then bring up that vlan. If it defines an interface or `all` then use LLDP info to figure out which VLANs should be brought up.

Parameters

interfaces_list List of current interfaces

Returns

List of vlan interface names that have been added

`ironic_python_agent.netutils.get_default_ip_addr`(*type, interface_id*)

Retrieve default IPv4 or IPv6 address.

`ironic_python_agent.netutils.get_hostname`()

`ironic_python_agent.netutils.get_ipv4_addr`(*interface_id*)

`ironic_python_agent.netutils.get_ipv6_addr`(*interface_id*)

`ironic_python_agent.netutils.get_lldp_info`(*interface_names*)

Get LLDP info from the switch(es) the agent is connected to.

Listens on either a single or all interfaces for LLDP packets, then parses them. If no LLDP packets are received before `lldp_timeout`, returns a dictionary in the form `{interface: [],}`.

Parameters

interface_names The interface to listen for packets on. If `None`, will listen on each interface.

Returns

A dictionary in the form `{interface: [(lldp_type, lldp_data)],}`

`ironic_python_agent.netutils.get_mac_addr`(*interface_id*)

`ironic_python_agent.netutils.get_wildcard_address`()

class `ironic_python_agent.netutils.ifreq`

Bases: `Structure`

Class for setting flags on a socket.

ifr_flags

Structure/Union member

ifr_ifrn

Structure/Union member

`ironic_python_agent.netutils.interface_has_carrier`(*interface_name*)

```
ironic_python_agent.netutils.is_bond(interface_name)
```

```
ironic_python_agent.netutils.is_network_device(interface_name)
```

```
ironic_python_agent.netutils.is_vlan(interface_name)
```

```
ironic_python_agent.netutils.list_interfaces()
```

```
ironic_python_agent.netutils.wrap_ipv6(ip)
```

ironic_python_agent.numa_inspector module

```
ironic_python_agent.numa_inspector.collect_numa_topology_info(data, failures)
```

Collect the NUMA topology information.

The data is gathered from `/sys/devices/system/node/node<X>` and `/sys/class/net/` directories. The information is collected in the form of:

```
{
  "numa_topology": {
    "ram": [{"numa_node": <numa_node_id>, "size_kb": <memory_in_kb>},
           ...],
    "cpus": [
      {
        "cpu": <cpu_id>, "numa_node": <numa_node_id>,
        "thread_siblings": [<list of sibling threads>]
      },
      ...
    ],
    "nics": [
      {"name": "<network interface name>", "numa_node": <numa_node_id>},
      ...
    ]
  }
}
```

Parameters

- **data** mutable data that will send to inspector
- **failures** AccumulatedFailures object

Returns

None

```
ironic_python_agent.numa_inspector.get_nodes_cores_info(numa_node_dirs)
```

Collect the NUMA nodes cpus and threads information.

NUMA nodes path: `/sys/devices/system/node/node<node_id>`

Thread dirs path: `/sys/devices/system/node/node<node_id>/cpu<thread_id>`

CPU id file path: `/sys/devices/system/node/node<node_id>/cpu<thread_id>/topology/core_id`

The information is returned in the form of:

```
"cpus": [
  {
    "cpu": <cpu_id>, "numa_node": <numa_node_id>,
    "thread_siblings": [<list of sibling threads>]
  },
  ...,
]
```

Parameters

numa_node_dirs A list of NUMA node directories

Raises

IncompatibleNumaFormatError: when unexpected format data in NUMA node

Returns

A list of cpu information with NUMA node id and thread siblings

`ironic_python_agent.numa_inspector.get_nodes_memory_info(numa_node_dirs)`

Collect the NUMA nodes memory information.

The information is returned in the form of:

```
"ram": [{"numa_node": <numa_node_id>, "size_kb": <memory_in_kb>}, ...]
```

Parameters

numa_node_dirs A list of NUMA node directories

Raises

IncompatibleNumaFormatError: when unexpected format data in NUMA node

Returns

A list of memory information with NUMA node id

`ironic_python_agent.numa_inspector.get_nodes_nics_info(nic_device_path)`

Collect the NUMA nodes nics information.

The information is returned in the form of:

```
"nics": [
  {"name": "<network interface name>",
    "numa_node": <numa_node_id>},
  ...,
]
```

Parameters

nic_device_path nic device directory path

Raises

IncompatibleNumaFormatError: when unexpected format data in NUMA node

Returns

A list of nics information with NUMA node id

`ironic_python_agent.numa_inspector.get_numa_node_id(numa_node_dir)`

Provides the NUMA node id from NUMA node directory

Parameters

numa_node_dir NUMA node directory

Raises

`IncompatibleNumaFormatError`: when unexpected format data in NUMA node dir

Returns

NUMA node id

ironic_python_agent.partition_utils module

Logic related to handling partitions.

Imported from `ironic-lib` `disk_utils` as of the following commit: <https://opendev.org/openstack/ironic-lib/commit/9fb5be348202f4854a455cd08f400ae12b99e1f2>

`ironic_python_agent.partition_utils.create_config_drive_partition(node_uuid,
device,
configdrive)`

Create a partition for config drive

Checks if the device is GPT or MBR partitioned and creates config drive partition accordingly.

Parameters

- **node_uuid** UUID of the Node.
- **device** The device path.
- **configdrive** Base64 encoded Gzipped configdrive content or configdrive HTTP URL.

Raises

`InstanceDeployFailure` if config drive size exceeds maximum limit or if it fails to create config drive.

`ironic_python_agent.partition_utils.get_configdrive(configdrive, node_uuid,
tempdir=None)`

Get the information about size and location of the configdrive.

Parameters

- **configdrive** Base64 encoded Gzipped configdrive content or configdrive HTTP URL.
- **node_uuid** Nodes uuid. Used for logging.
- **tempdir** temporary directory for the temporary configdrive file

Raises

`InstanceDeployFailure` if it cant download or decode the config drive.

Returns

A tuple with the size in MiB and path to the uncompressed configdrive file.

`ironic_python_agent.partition_utils.get_labelled_partition(device_path, label, node_uuid)`

Check and return if partition with given label exists

Parameters

- **device_path** The device path.
- **label** Partition label
- **node_uuid** UUID of the Node. Used for logging.

Raises

`InstanceDeployFailure`, if any disk partitioning related commands fail.

Returns

block device file for partition if it exists; otherwise it returns `None`.

`ironic_python_agent.partition_utils.get_partition(device, uuid)`

Find the partition of a given device.

`ironic_python_agent.partition_utils.work_on_disk(dev, root_mb, swap_mb, ephemeral_mb, ephemeral_format, image_path, node_uuid, preserve_ephemeral=False, configdrive=None, boot_mode='bios', tempdir=None, disk_label=None, cpu_arch="", conv_flags=None)`

Create partitions and copy an image to the root partition.

Parameters

- **dev** Path for the device to work on.
- **root_mb** Size of the root partition in megabytes.
- **swap_mb** Size of the swap partition in megabytes.
- **ephemeral_mb** Size of the ephemeral partition in megabytes. If 0, no ephemeral partition will be created.
- **ephemeral_format** The type of file system to format the ephemeral partition.
- **image_path** Path for the instances disk image. If `None`, the root partition is prepared but not populated.
- **node_uuid** nodes uuid. Used for logging.
- **preserve_ephemeral** If `True`, no filesystem is written to the ephemeral block device, preserving whatever content it had (if the partition table has not changed).
- **configdrive** Optional. Base64 encoded Gzipped configdrive content or configdrive HTTP URL.
- **boot_mode** Can be bios or uefi. bios by default.
- **tempdir** A temporary directory

- **disk_label** The disk label to be used when creating the partition table. Valid values are: msdos, gpt or None; If None Ironic will figure it out according to the boot_mode parameter.
- **cpu_arch** Architecture of the node the disk device belongs to. When using the default value of None, no architecture specific steps will be taken. This default should be used for x86_64. When set to ppc64*, architecture specific steps are taken for booting a partition image locally.
- **conv_flags** Flags that need to be sent to the dd command, to control the conversion of the original file when copying to the host. It can contain several options separated by commas.

Returns

a dictionary containing the following keys: root uuid: UUID of root partition efi system partition uuid: UUID of the uefi system partition (if boot mode is uefi). *partitions*: mapping of partition types to their device paths. NOTE: If key exists but value is None, it means partition doesn't exist.

ironic_python_agent.raid_utils module

`ironic_python_agent.raid_utils.calc_raid_partition_sectors(psize, start)`

Calculates end sector and converts start and end sectors including

the unit of measure, compatible with parted. :param psize: size of the raid partition :param start: start sector of the raid partition in integer format :return: start and end sector in parted compatible format, end sector

as integer

`ironic_python_agent.raid_utils.calculate_raid_start(target_boot_mode,
partition_table_type, dev_name)`

Define the start sector for the raid partition.

Parameters

- **target_boot_mode** the node boot mode.
- **partition_table_type** the node partition label, gpt or msdos.
- **dev_name** block device in the raid configuration.

Returns

The start sector for the raid partition.

`ironic_python_agent.raid_utils.create_raid_device(index, logical_disk)`

Create a raid device.

Parameters

- **index** the index of the resulting md device.
- **logical_disk** the logical disk containing the devices used to create the raid.

Raise

errors.SoftwareRAIDError if not able to create the raid device or fails to re-add a device to a raid.

`ironic_python_agent.raid_utils.create_raid_partition_tables`(*block_devices*,
partition_table_type,
target_boot_mode)

Creates partition tables in all disks in a RAID configuration and

reports the starting sector for each partition on each disk. :param *block_devices*: disks where we want to create the partition tables. :param *partition_table_type*: type of partition table to create, for example

`gpt` or `msdos`.

Parameters

`target_boot_mode` the node selected boot mode, for example `uefi` or `bios`.

Returns

a dictionary of devices and the start of the corresponding partition.

`ironic_python_agent.raid_utils.find_esp_raid`()

Find the ESP md device in case of a rebuild.

`ironic_python_agent.raid_utils.get_block_devices_for_raid`(*block_devices*,
logical_disks)

Get block devices that are involved in the RAID configuration.

This call does two things: * Collect all block devices that are involved in RAID. * Update each logical disks with suitable block devices.

`ironic_python_agent.raid_utils.get_next_free_raid_device`()

Get a device name that is still free.

`ironic_python_agent.raid_utils.get_volume_name_of_raid_device`(*raid_device*)

Get the volume name of a RAID device

Parameters

`raid_device` A Software RAID block device name.

Returns

volume name of the device, or `None`

`ironic_python_agent.raid_utils.prepare_boot_partitions_for_softraid`(*device*,
holders,
efi_part, *target_boot_mode*)

Prepare boot partitions when relevant.

Create either a RAIDed EFI partition or bios boot partitions for software RAID, according to both target boot mode and disk holders partition table types.

Parameters

- **`device`** the softraid device path
- **`holders`** the softraid drive members
- **`efi_part`** when relevant the efi partition coming from the image deployed on softraid device, can be/is often `None`

- **target_boot_mode** target boot mode can be bios/uefi/None or anything else for unspecified

Returns

the path to the ESP md device when target boot mode is uefi, nothing otherwise.

ironic_python_agent.tls_utils module

class `ironic_python_agent.tls_utils.TlsCertificate`(*text, path, private_key_path*)

Bases: tuple

path

Alias for field number 1

private_key_path

Alias for field number 2

text

Alias for field number 0

`ironic_python_agent.tls_utils.generate_tls_certificate`(*ip_address,*
common_name=None,
valid_for_days=90)

Generate a self-signed TLS certificate.

Parameters

- **ip_address** IP address the certificate will be valid for.
- **common_name** Content for the common name field (e.g. host name). Defaults to the current host name.
- **valid_for_days** Number of days the certificate will be valid for.

Returns

a TlsCertificate object.

ironic_python_agent.utils module

class `ironic_python_agent.utils.AccumulatedFailures`(*exc_class=<class*
'RuntimeError'>)

Bases: object

Object to accumulate failures without raising exception.

add(*fail, *fmt*)

Add failure with optional formatting.

Parameters

- **fail** exception or error string
- **fmt** formatting arguments (only if fail is a string)

get_error()

Get error string or None.

raise_if_needed()

Raise exception if error list is not empty.

Raises

RuntimeError

class `ironic_python_agent.utils.StreamingClient`(*verify_ca=True*)

Bases: object

A wrapper around HTTP client with TLS, streaming and error handling.

`ironic_python_agent.utils.collect_system_logs`(*journald_max_lines=None*)

Collect system logs.

Collect system logs, for distributions using systemd the logs will come from journald. On other distributions the logs will come from the /var/log directory and dmesg output.

Parameters

journald_max_lines Maximum number of lines to retrieve from the journald. if None, return everything.

Returns

A tar, gzip base64 encoded string with the logs.

`ironic_python_agent.utils.copy_config_from_vmedia`()

Copies any configuration from a virtual media device.

Copies files under /etc/ironic-python-agent and /etc/ironic-python-agent.d.

`ironic_python_agent.utils.create_partition_table`(*dev_name, partition_table_type*)

Create a partition table on a disk using parted.

Parameters

- **dev_name** the disk where we want to create the partition table.
- **partition_table_type** the type of partition table we want to create, for example gpt or msdos.

Raises

CommandExecutionError if an error is encountered while attempting to create the partition table.

`ironic_python_agent.utils.determine_time_method`()

Helper method to determine what time utility is present.

Returns

ntupdate if ntpdate has been found, chrony if chrony was located, and None if neither are located. If both tools are present, chrony will supercede ntpdate.

`ironic_python_agent.utils.execute`(**cmd*, ***kwargs*)

Convenience wrapper around ironic_libs execute() method.

Executes and logs results from a system command.

`ironic_python_agent.utils.extract_device(part)`

Extract the device from a partition name or path.

Parameters

part the partition

Returns

a device if success, None otherwise

`ironic_python_agent.utils.find_in_lshw(lshw, by_id=None, by_class=None, recursive=False, **fields)`

Yield all suitable records from lshw.

`ironic_python_agent.utils.get_agent_params()`

Gets parameters passed to the agent via kernel cmdline or vmedia.

Parameters can be passed using either the kernel commandline or through virtual media. If `boot_method` is `vmedia`, merge params provided via `vmedia` with those read from the kernel command line.

Although it should never happen, if a variable is both set by `vmedia` and kernel command line, the setting in `vmedia` will take precedence.

Returns

a dict of potential configuration parameters for the agent

`ironic_python_agent.utils.get_command_output(command)`

Return the output of a given command.

Parameters

command The command to be executed.

Raises

`CommandExecutionError` if the execution of the command fails.

Returns

A BytesIO string with the output.

`ironic_python_agent.utils.get_journalctl_output(lines=None, units=None)`

Query the contents of the systemd journal.

Parameters

- **lines** Maximum number of lines to retrieve from the logs. If `None`, return everything.
- **units** A list with the names of the units we should retrieve the logs from. If `None` retrieve the logs for everything.

Returns

A log string.

`ironic_python_agent.utils.get_node_boot_mode(node)`

Returns the node boot mode.

It returns `uefi` if `secure_boot` is set to `true` in `instance_info/capabilities` of `node`. Otherwise it directly look for boot mode hints into

Parameters

node dictionary.

Returns

bios or uefi

`ironic_python_agent.utils.get_partition_table_type_from_specs(node)`

Returns the node partition label, gpt or msdos.

If boot mode is uefi, return gpt. Else, choice is open, look for disk_label capabilities (instance_info has priority over properties).

Parameters

node

Returns

gpt or msdos

`ironic_python_agent.utils.get_ssl_client_options(conf)`

Format SSL-related requests options.

Parameters

conf oslo_config CONF object

Returns

tuple of verify and cert values to pass to requests

`ironic_python_agent.utils.guess_root_disk(block_devices,
min_size_required=4294967296)`

Find suitable disk provided that root device hints are not given.

If no hints are passed, order the devices by size (primary key) and name (secondary key), and return the first device larger than min_size_required as the root disk.

`ironic_python_agent.utils.gzip_and_b64encode(io_dict=None, file_list=None)`

Gzip and base64 encode files and BytesIO buffers.

Parameters

- **io_dict** A dictionary containing whose the keys are the file names and the value a BytesIO object.
- **file_list** A list of file path.

Returns

A gzipped and base64 encoded string.

`ironic_python_agent.utils.is_journalctl_present()`

Check if the journalctl command is present.

Returns

True if journalctl is present, False if not.

`ironic_python_agent.utils.log_early_log_to_logger()`

Logs early logging events to the configured logger.

`ironic_python_agent.utils.parse_capabilities(root)`

Extract capabilities from provided root dictionary-behaving object.

root.get(capabilities, {}) value can either be a dict, or a json str, or a key1:value1,key2:value2 formatted string.

Parameters

root Anything behaving like a dict and containing capabilities formatted as expected. Can be `node.get(properties, {})`, `node.get(instance_info, {})`.

Returns

A dictionary with the capabilities if found and well formatted, otherwise an empty dictionary.

`ironic_python_agent.utils.remove_large_keys(var)`

Remove specific keys from the var, recursing into dicts and lists.

`ironic_python_agent.utils.rescan_device(device)`

Force the device to be rescanned

Parameters

device device upon which to rescan and update kernel partition records.

`ironic_python_agent.utils.split_device_and_partition_number(part)`

Extract the partition number from a partition name or path.

Parameters

part the partition

Returns

device and partition number if success, None otherwise

`ironic_python_agent.utils.sync_clock(ignore_errors=False)`

Syncs the software clock of the system.

This method syncs the system software clock if a NTP server was defined in the [DEFAULT]ntp_server configuration parameter. This method does NOT attempt to sync the hardware clock.

It will try to use either ntpdate or chrony to sync the software clock of the system. If neither is found, an exception is raised.

Parameters

ignore_errors Boolean value default False that allows for the method to be called and ultimately not raise an exception. This may be useful for opportunistically attempting to sync the system software clock.

Raises

CommandExecutionError if an error is encountered while attempting to sync the software clock.

`ironic_python_agent.utils.try_collect_command_output(io_dict, file_name, command)`

ironic_python_agent.version module

Module contents

INDICES AND TABLES

- `genindex`
- `search`

PYTHON MODULE INDEX

.

- `ironic_python_agent.agent`, 37
- `ironic_python_agent.api`, 28
- `ironic_python_agent.api.app`, 27
- `ironic_python_agent.burnin`, 39
- `ironic_python_agent.cmd`, 29
- `ironic_python_agent.cmd.agent`, 28
- `ironic_python_agent.cmd.inspect`, 29
- `ironic_python_agent.config`, 40
- `ironic_python_agent.dmi_inspector`, 41
- `ironic_python_agent.efi_utils`, 41
- `ironic_python_agent.encoding`, 42
- `ironic_python_agent.errors`, 43
- `ironic_python_agent.extensions`, 36
- `ironic_python_agent.extensions.base`, 29
- `ironic_python_agent.extensions.clean`, 31
- `ironic_python_agent.extensions.deploy`, 32
- `ironic_python_agent.extensions.flow`, 32
- `ironic_python_agent.extensions.image`, 32
- `ironic_python_agent.extensions.log`, 33
- `ironic_python_agent.extensions.poll`, 33
- `ironic_python_agent.extensions.rescue`, 34
- `ironic_python_agent.extensions.service`, 34
- `ironic_python_agent.extensions.standby`, 35
- `ironic_python_agent.hardware`, 47
- `ironic_python_agent.hardware_managers`, 37
- `ironic_python_agent.hardware_managers.cna`, 36
- `ironic_python_agent.hardware_managers.mlnx`, 36
- `ironic_python_agent.inject_files`, 67
- `ironic_python_agent.inspect`, 67
- `ironic_python_agent.inspector`, 68
- `ironic_python_agent.ironic_api_client`, 69
- `ironic_python_agent.netutils`, 70
- `ironic_python_agent.numa_inspector`, 71
- `ironic_python_agent.partition_utils`, 73
- `ironic_python_agent.raid_utils`, 75
- `ironic_python_agent.tls_utils`, 77
- `ironic_python_agent.utils`, 77
- `ironic_python_agent.version`, 82

i

- `ironic_python_agent`, 82

INDEX

A

AccumulatedFailures (class in *ironic_python_agent.utils*), 77

add() (*ironic_python_agent.utils.AccumulatedFailures* method), 77

add_boot_record() (in module *ironic_python_agent.efi_utils*), 41

agent_token (*ironic_python_agent.ironic_api_client.APIClient* attribute), 69

AgentCommandStatus (class in *ironic_python_agent.extensions.base*), 29

AgentIsBusy, 43

api_get_command() (*ironic_python_agent.api.app.Application* method), 27

api_list_commands() (*ironic_python_agent.api.app.Application* method), 28

api_root() (*ironic_python_agent.api.app.Application* method), 28

api_run_command() (*ironic_python_agent.api.app.Application* method), 28

api_status() (*ironic_python_agent.api.app.Application* method), 28

api_v1() (*ironic_python_agent.api.app.Application* method), 28

api_version (*ironic_python_agent.ironic_api_client.APIClient* attribute), 69

APIClient (class in *ironic_python_agent.ironic_api_client*), 69

Application (class in *ironic_python_agent.api.app*), 27

apply_configuration() (*ironic_python_agent.hardware.GenericHardwareManager* method), 48

async_command() (in module *ironic_python_agent.extensions.base*), 30

AsyncCommandResult (class in *ironic_python_agent.extensions.base*), 29

B

backoff_factor (*ironic_python_agent.inspect.IronicInspection* attribute), 67

BaseAgentExtension (class in *ironic_python_agent.extensions.base*), 30

BaseCommandResult (class in *ironic_python_agent.extensions.base*), 30

BlockDevice (class in *ironic_python_agent.hardware*), 47

BlockDeviceEraseError, 43

BlockDeviceError, 43

BootInfo (class in *ironic_python_agent.hardware*), 47

bring_up_vlan_interfaces() (in module *ironic_python_agent.netutils*), 70

burnin_cpu() (*ironic_python_agent.hardware.GenericHardwareManager* method), 48

burnin_disk() (*ironic_python_agent.hardware.GenericHardwareManager* method), 48

burnin_memory() (*ironic_python_agent.hardware.GenericHardwareManager* method), 48

burnin_network() (*ironic_python_agent.hardware.GenericHardwareManager* method), 48

bytes_transferred (*ironic_python_agent.extensions.standby.ImageDownload* property), 35

C

cache_node() (in module *ironic_python_agent.hardware*), 62

calc_raid_partition_sectors() (in module *ironic_python_agent.raid_utils*), 75

calculate_raid_start() (in module *ironic_python_agent.raid_utils*), 75

call_inspector() (in module *ironic_python_agent.inspector*), 68

check_cmd_presence() (*ironic_python_agent.extensions.base.BaseAgentExtension* method), 30

method), 30

check_md5_enabled() (in module *ironic_python_agent.extensions.standby*), 36

check_versions() (in module *ironic_python_agent.hardware*), 62

CleanExtension (class in *ironic_python_agent.extensions.clean*), 31

CleaningError, 43

ClockSyncError, 43

collect_default() (in module *ironic_python_agent.inspector*), 68

collect_dmidecode_info() (in module *ironic_python_agent.dmi_inspector*), 41

collect_extra_hardware() (in module *ironic_python_agent.inspector*), 68

collect_lldp() (in module *ironic_python_agent.inspector*), 68

collect_lldp_data() (*ironic_python_agent.hardware.GenericHardwareManager* method), 48

collect_lldp_data() (*ironic_python_agent.hardware.HardwareManager* method), 56

collect_logs() (in module *ironic_python_agent.inspector*), 68

collect_numa_topology_info() (in module *ironic_python_agent.numa_inspector*), 71

collect_pci_devices_info() (in module *ironic_python_agent.inspector*), 68

collect_system_logs() (in module *ironic_python_agent.utils*), 78

collect_system_logs() (*ironic_python_agent.extensions.log.LogExtension* method), 33

collect_system_logs() (*ironic_python_agent.hardware.GenericHardwareManager* method), 49

collect_system_logs() (*ironic_python_agent.hardware.HardwareManager* method), 56

CommandExecutionError, 43

content_length (*ironic_python_agent.extensions.standby.ImageDownload* property), 35

copy_config_from_vmedia() (in module *ironic_python_agent.utils*), 78

CPU (class in *ironic_python_agent.hardware*), 47

create_config_drive_partition() (in module *ironic_python_agent.partition_utils*), 73

create_configuration() (*ironic_python_agent.hardware.GenericHardwareManager* method), 49

create_partition_table() (in module *ironic_python_agent.utils*), 78

create_raid_device() (in module *ironic_python_agent.raid_utils*), 75

create_raid_partition_tables() (in module *ironic_python_agent.raid_utils*), 75

D

deduplicate_steps() (in module *ironic_python_agent.hardware*), 63

default() (*ironic_python_agent.encoding.RESTJSONEncoder* method), 42

delete_configuration() (*ironic_python_agent.hardware.GenericHardwareManager* method), 49

DeployExtension (class in *ironic_python_agent.extensions.deploy*), 32

DeploymentError, 43

details (*ironic_python_agent.errors.NotFound* attribute), 46

details (*ironic_python_agent.errors.RESTError* attribute), 46

details_str (*ironic_python_agent.errors.ImageChecksumError* attribute), 44

determine_time_method() (in module *ironic_python_agent.utils*), 78

DeviceNotFound, 43

dispatch_to_all_managers() (in module *ironic_python_agent.hardware*), 63

dispatch_to_managers() (in module *ironic_python_agent.hardware*), 63

do_heartbeat() (*ironic_python_agent.agent.IronicPythonAgentHeartbeat* method), 39

E

encode() (*ironic_python_agent.encoding.RESTJSONEncoder* method), 42

erase_block_device() (*ironic_python_agent.hardware.GenericHardwareManager* method), 49

erase_block_device() (*ironic_python_agent.hardware.HardwareManager* method), 56

erase_devices() (*ironic_python_agent.hardware.HardwareManager*

method), 57
 erase_devices_express() (*ironic_python_agent.hardware.GenericHardwareManager* *method*), 50
 erase_devices_metadata() (*ironic_python_agent.hardware.GenericHardwareManager* *method*), 50
 erase_pstore() (*ironic_python_agent.hardware.GenericHardwareManager* *method*), 51
 evaluate_hardware_support() (*ironic_python_agent.hardware.GenericHardwareManager* *method*), 51
 evaluate_hardware_support() (*ironic_python_agent.hardware.HardwareManager* *method*), 57
 evaluate_hardware_support() (*ironic_python_agent.hardware_managers.cna.IntelCnaworkloadManager* *method*), 36
 evaluate_hardware_support() (*ironic_python_agent.hardware_managers.mlnx.MellanoxIronicPythonAgentManager* *method*), 37
 execute() (*in module ironic_python_agent.utils*), 78
 execute() (*ironic_python_agent.extensions.base.BaseAgentExtension* *method*), 30
 execute_clean_step() (*ironic_python_agent.extensions.clean.CleanExtension* *method*), 31
 execute_command() (*ironic_python_agent.extensions.base.ExecuteCommandMixin* *method*), 30
 execute_deploy_step() (*ironic_python_agent.extensions.deploy.DeployExtension* *method*), 32
 execute_service_step() (*ironic_python_agent.extensions.service.ServiceExtension* *method*), 34
 ExecuteCommandMixin (*class in ironic_python_agent.extensions.base*), 30
 extension_manager() (*in module ironic_python_agent.inspector*), 69
 ExtensionError, 43
 extract_device() (*in module ironic_python_agent.utils*), 78
F
 FAILED (*ironic_python_agent.extensions.base.AgentCommandStatus* *attribute*), 29
 finalize_rescue() (*ironic_python_agent.extensions.rescue.RescueExtension* *method*), 34
 find_esp_raid() (*in module ironic_python_agent.raid_utils*), 76
 find_in_lshw() (*in module ironic_python_agent.utils*), 79
 find_partitions_with_path() (*in module ironic_python_agent.inject_files*), 67
 fio_disk() (*in module ironic_python_agent.burnin*), 39
 fio_network() (*in module ironic_python_agent.burnin*), 39
 FlowExtension (*class in ironic_python_agent.extensions.flow*), 32
 force_heartbeat() (*ironic_python_agent.agent.IronicPythonAgent* *method*), 38
 force_heartbeat() (*ironic_python_agent.agent.IronicPythonAgentHeartbeat* *method*), 39
 format_exception() (*in module ironic_python_agent.exceptions*), 28
G
 generate_tls_certificate() (*in module ironic_python_agent.tls_utils*), 77
 generate_tls_certificate() (*ironic_python_agent.hardware.GenericHardwareManager* *method*), 51
 generate_tls_certificate() (*ironic_python_agent.hardware.HardwareManager* *method*), 57
 GENERIC (*ironic_python_agent.hardware.HardwareSupport* *attribute*), 61
 GenericHardwareManager (*class in ironic_python_agent.hardware*), 48
 get_agent_params() (*in module ironic_python_agent.utils*), 79
 get_bios_given_nic_name() (*ironic_python_agent.hardware.GenericHardwareManager* *method*), 51
 get_block_devices_for_raid() (*in module ironic_python_agent.raid_utils*), 76
 get_bmc_address() (*ironic_python_agent.hardware.GenericHardwareManager* *method*), 51
 get_bmc_address() (*ironic_python_agent.hardware.HardwareManager* *method*), 57
 get_bmc_mac() (*ironic_python_agent.hardware.GenericHardwareManager* *method*), 51
 get_bmc_mac() (*ironic_python_agent.hardware.HardwareManager* *method*), 51

method), 57
 get_bmc_v6address() (ironic_python_agent.hardware.GenericHardwareManager method), 52
 get_bmc_v6address() (ironic_python_agent.hardware.GenericHardwareManager method), 51
 get_bmc_v6address() (ironic_python_agent.hardware.HardwareManager method), 58
 get_boot_info() (ironic_python_agent.hardware.GenericHardwareManager method), 57
 get_boot_info() (ironic_python_agent.hardware.HardwareManager method), 37
 get_boot_info() (ironic_python_agent.hardware.GenericHardwareManager method), 51
 get_boot_info() (ironic_python_agent.hardware.HardwareManager method), 57
 get_boot_records() (in module ironic_python_agent.efi_utils), 41
 get_cached_node() (in module ironic_python_agent.hardware), 64
 get_clean_steps() (ironic_python_agent.extensions.clean.CleanExtension method), 31
 get_clean_steps() (ironic_python_agent.hardware.GenericHardwareManager method), 51
 get_clean_steps() (ironic_python_agent.hardware.HardwareManager method), 57
 get_clean_steps() (ironic_python_agent.hardware_managers.mlnx.MellanoxHardwareManager method), 37
 get_command_output() (in module ironic_python_agent.utils), 79
 get_command_result() (ironic_python_agent.agent.IroniCPythonAgent method), 38
 get_component_devices() (in module ironic_python_agent.hardware), 64
 get_configdrive() (in module ironic_python_agent.partition_utils), 73
 get_cpus() (ironic_python_agent.hardware.GenericHardwareManager method), 52
 get_cpus() (ironic_python_agent.hardware.HardwareManager method), 58
 get_current_versions() (in module ironic_python_agent.hardware), 64
 get_default_ip_addr() (in module ironic_python_agent.netutils), 70
 get_deploy_steps() (ironic_python_agent.extensions.deploy.DeployExtension method), 32
 get_deploy_steps() (ironic_python_agent.hardware.GenericHardwareManager method), 52
 get_deploy_steps() (ironic_python_agent.hardware.HardwareManager method), 58
 get_deploy_steps() (ironic_python_agent.hardware_managers.mlnx.MellanoxHardwareManager method), 37
 get_extension() (in module ironic_python_agent.extensions.base), 31
 get_extension() (ironic_python_agent.extensions.base.ExecuteCommandMethod method), 30
 get_extension() (ironic_python_agent.extensions.poll.PollExtension method), 33
 get_ext_holders_disks() (in module ironic_python_agent.hardware), 64
 get_hostname() (in module ironic_python_agent.netutils), 70
 get_interface_info() (ironic_python_agent.hardware.GenericHardwareManager method), 53
 get_interface_info() (ironic_python_agent.hardware.HardwareManager method), 59
 get_interface_info() (ironic_python_agent.hardware_managers.mlnx.MellanoxHardwareManager method), 37
 get_ipv4_addr() (in module ironic_python_agent.netutils), 70
 get_ipv4_addr() (ironic_python_agent.hardware.GenericHardwareManager method), 53
 get_ipv6_addr() (in module ironic_python_agent.netutils), 70
 get_ipv6_addr() (ironic_python_agent.hardware.GenericHardwareManager method), 53
 get_journaldctl_output() (in module ironic_python_agent.utils), 79
 get_labelled_partition() (in module ironic_python_agent.partition_utils), 73
 get_lldp_info() (in module ironic_python_agent.netutils), 70
 get_mac_addr() (in module ironic_python_agent.netutils), 70
 get_managers() (in module ironic_python_agent.hardware), 64

`get_memory()` (`ironic_python_agent.hardware.GenericHardwareManager` method), 53
`get_memory()` (`ironic_python_agent.hardware.HardwareManager` method), 59
`get_multipath_status()` (in module `ironic_python_agent.hardware`), 65
`get_next_free_raid_device()` (in module `ironic_python_agent.raid_utils`), 76
`get_node_boot_mode()` (in module `ironic_python_agent.utils`), 79
`get_node_uuid()` (`ironic_python_agent.agent.IronicPythonAgent` method), 38
`get_nodes_cores_info()` (in module `ironic_python_agent.numa_inspector`), 71
`get_nodes_memory_info()` (in module `ironic_python_agent.numa_inspector`), 72
`get_nodes_nics_info()` (in module `ironic_python_agent.numa_inspector`), 72
`get_numa_node_id()` (in module `ironic_python_agent.numa_inspector`), 73
`get_os_install_device()` (`ironic_python_agent.hardware.GenericHardwareManager` method), 53
`get_os_install_device()` (`ironic_python_agent.hardware.HardwareManager` method), 59
`get_partition()` (in module `ironic_python_agent.partition_utils`), 74
`get_partition_path_by_number()` (in module `ironic_python_agent.efi_utils`), 41
`get_partition_table_type_from_specs()` (in module `ironic_python_agent.utils`), 80
`get_partition_uuids()` (`ironic_python_agent.extensions.standby.StandbyExtension` attribute), 36
`get_service_steps()` (`ironic_python_agent.extensions.service.ServiceExtension` attribute), 48
`get_service_steps()` (`ironic_python_agent.hardware.GenericHardwareManager` method), 53
`get_service_steps()` (`ironic_python_agent.hardware.HardwareManager` method), 59
`get_service_steps()` (`ironic_python_agent.hardware.GenericHardwareManager` attribute), 36
`get_skip_list_from_node()` (`ironic_python_agent.hardware.GenericHardwareManager` method), 54
`get_skip_list_from_node()` (`ironic_python_agent.hardware.HardwareManager` method), 60
`get_ssl_client_options()` (in module `ironic_python_agent.utils`), 80
`get_status()` (`ironic_python_agent.agent.IronicPythonAgent` method), 38
`get_system_vendor_info()` (`ironic_python_agent.hardware.GenericHardwareManager` method), 55
`get_version()` (`ironic_python_agent.hardware.HardwareManager` method), 60
`get_volume_name_of_raid_device()` (in module `ironic_python_agent.raid_utils`), 76
`get_wildcard_address()` (in module `ironic_python_agent.netutils`), 70
`guess_root_disk()` (in module `ironic_python_agent.utils`), 80
`gzip_and_b64encode()` (in module `ironic_python_agent.utils`), 80

H

`handle_exception()` (`ironic_python_agent.api.app.Application` method), 28
HARDWARE_MANAGER_NAME (`ironic_python_agent.hardware.GenericHardwareManager` attribute), 48
HARDWARE_MANAGER_NAME (`ironic_python_agent.hardware_managers.cna.IntelCnaHardwareManager` attribute), 36
HARDWARE_MANAGER_NAME (`ironic_python_agent.hardware_managers.mlnx.MellanoxHardwareManager` attribute), 36
HARDWARE_MANAGER_VERSION (`ironic_python_agent.hardware.GenericHardwareManager` attribute), 48
HARDWARE_MANAGER_VERSION (`ironic_python_agent.hardware_managers.cna.IntelCnaHardwareManager` attribute), 36
HARDWARE_MANAGER_VERSION (`ironic_python_agent.hardware_managers.mlnx.MellanoxHardwareManager` attribute), 36
HardwareManager (class in `ironic_python_agent.hardware`), 56

HardwareManagerMethodNotFound, 44

HardwareManagerNotFound, 44

HardwareSupport (class in *ironic_python_agent.hardware*), 61

HardwareType (class in *ironic_python_agent.hardware*), 62

heartbeat() (*ironic_python_agent.ironic_api_client.APIClient* method), 69

heartbeat_api (*ironic_python_agent.ironic_api_client.APIClient* attribute), 69

HeartbeatConflictError, 44

HeartbeatConnectionError, 44

HeartbeatError, 44

Host (class in *ironic_python_agent.agent*), 37

hostname (*ironic_python_agent.agent.Host* attribute), 37

|

ifr_flags (*ironic_python_agent.netutils.ifreq* attribute), 70

ifr_ifrn (*ironic_python_agent.netutils.ifreq* attribute), 70

ifreq (class in *ironic_python_agent.netutils*), 70

ImageChecksumError, 44

ImageDownload (class in *ironic_python_agent.extensions.standby*), 35

ImageDownloadError, 44

ImageExtension (class in *ironic_python_agent.extensions.image*), 32

ImageWriteError, 44

IncompatibleHardwareMethodError, 45

IncompatibleNumaFormatError, 45

init_ext_manager() (in module *ironic_python_agent.extensions.base*), 31

inject_files() (in module *ironic_python_agent.inject_files*), 67

inject_files() (*ironic_python_agent.hardware.GenericHardwareManager* method), 55

inspect() (in module *ironic_python_agent.inspector*), 69

InspectionError, 45

install_bootloader() (*ironic_python_agent.extensions.image.ImageExtension* method), 32

IntelCnaHardwareManager (class in *ironic_python_agent.hardware_managers.cna*), 36

interface_has_carrier() (in module *ironic_python_agent.netutils*), 70

ironic_python_agent.agent module, 37

ironic_python_agent.api module, 28

ironic_python_agent.api.app module, 27

ironic_python_agent.burnin module, 39

ironic_python_agent.cmd module, 29

ironic_python_agent.cmd.agent module, 28

ironic_python_agent.cmd.inspect module, 29

ironic_python_agent.config module, 40

ironic_python_agent.dmi_inspector module, 41

ironic_python_agent.efi_utils module, 41

ironic_python_agent.encoding module, 42

ironic_python_agent.errors module, 43

ironic_python_agent.extensions module, 36

ironic_python_agent.extensions.base module, 29

ironic_python_agent.extensions.clean module, 31

ironic_python_agent.extensions.deploy module, 32

ironic_python_agent.extensions.flow module, 32

ironic_python_agent.extensions.image module, 32

ironic_python_agent.extensions.log module, 33

ironic_python_agent.extensions.poll module, 33

ironic_python_agent.extensions.rescue module, 34

ironic_python_agent.extensions.service module, 34

ironic_python_agent.extensions.standby

module, 35
 ironic_python_agent.hardware module, 47
 ironic_python_agent.hardware_managers module, 37
 ironic_python_agent.hardware_managers.cnx module, 36
 ironic_python_agent.hardware_managers.mlx module, 36
 ironic_python_agent.inject_files module, 67
 ironic_python_agent.inspect module, 67
 ironic_python_agent.inspector module, 68
 ironic_python_agent.ironic_api_client module, 69
 ironic_python_agent.netutils module, 70
 ironic_python_agent.numa_inspector module, 71
 ironic_python_agent.partition_utils module, 73
 ironic_python_agent.raid_utils module, 75
 ironic_python_agent.tls_utils module, 77
 ironic_python_agent.utils module, 77
 ironic_python_agent.version module, 82
 IronicAPIError, 45
 IronicInspection (class in *ironic_python_agent.inspect*), 67
 IronicPythonAgent (class in *ironic_python_agent.agent*), 37
 IronicPythonAgentHeartbeater (class in *ironic_python_agent.agent*), 39
 IronicPythonAgentStatus (class in *ironic_python_agent.agent*), 39
 is_bond() (in module *ironic_python_agent.netutils*), 70
 is_done() (*ironic_python_agent.extensions.base.AsyncCommandResult* method), 29
 is_done() (*ironic_python_agent.extensions.base.BaseCommandResult* method), 30
 is_journalctl_present() (in module *ironic_python_agent.utils*), 80
 is_md_device() (in module *ironic_python_agent.hardware*), 65
 is_network_device() (in module *ironic_python_agent.netutils*), 71
 is_vlan() (in module *ironic_python_agent.netutils*), 71

J

join() (*ironic_python_agent.extensions.base.AsyncCommandResult* method), 29
 join() (*ironic_python_agent.extensions.base.BaseCommandResult* method), 30
 jsonify() (in module *ironic_python_agent.api.app*), 28

L

list_all_block_devices() (in module *ironic_python_agent.hardware*), 65
 list_block_devices() (*ironic_python_agent.hardware.GenericHardwareManager* method), 55
 list_block_devices() (*ironic_python_agent.hardware.HardwareManager* method), 61
 list_block_devices_check_skip_list() (*ironic_python_agent.hardware.GenericHardwareManager* method), 55
 list_block_devices_check_skip_list() (*ironic_python_agent.hardware.HardwareManager* method), 61
 list_command_results() (*ironic_python_agent.agent.IronicPythonAgent* method), 38
 list_hardware_info() (in module *ironic_python_agent.hardware*), 65
 list_hardware_info() (*ironic_python_agent.hardware.GenericHardwareManager* method), 55
 list_hardware_info() (*ironic_python_agent.hardware.HardwareManager* method), 61
 list_interfaces() (in module *ironic_python_agent.netutils*), 71
 list_network_interfaces() (*ironic_python_agent.hardware.GenericHardwareManager* method), 55
 list_network_interfaces() (*ironic_python_agent.hardware.HardwareManager* method), 61
 list_opts() (in module *ironic_python_agent.config*), 40
 log_early_log_to_logger() (in module *ironic_python_agent.utils*), 80
 LogExtension (class in *ironic_python_agent.extensions.log*),

33

lookup_api (ironic_python_agent.ironic_api_client.APIClient attribute), 69

lookup_lock_pause (ironic_python_agent.ironic_api_client.APIClient attribute), 69

lookup_node() (ironic_python_agent.ironic_api_client.APIClient method), 69

LookupAgentIPError, 45

LookupNodeError, 46

M

MAC_ADDRESS (ironic_python_agent.hardware.HardwareManager attribute), 62

MAINLINE (ironic_python_agent.hardware.HardwareManager attribute), 61

make_link() (in module ironic_python_agent.api.app), 28

manage_uefi() (in module ironic_python_agent.efi_utils), 41

max_delay (ironic_python_agent.inspect.IronicInspector attribute), 67

max_jitter_multiplier (ironic_python_agent.agent.IronicPythonAgentHeartbeat attribute), 39

max_jitter_multiplier (ironic_python_agent.inspect.IronicInspector attribute), 67

md_get_raid_devices() (in module ironic_python_agent.hardware), 65

md_restart() (in module ironic_python_agent.hardware), 66

MellanoxDeviceHardwareManager (class in ironic_python_agent.hardware_managers.mlnx), 36

Memory (class in ironic_python_agent.hardware), 62

message (ironic_python_agent.errors.AgentIsBusy attribute), 43

message (ironic_python_agent.errors.BlockDeviceEraseError attribute), 43

message (ironic_python_agent.errors.BlockDeviceError attribute), 43

message (ironic_python_agent.errors.CleaningError attribute), 43

message (ironic_python_agent.errors.ClockSyncError attribute), 43

message (ironic_python_agent.errors.CommandExecutionError attribute), 43

message (ironic_python_agent.errors.DeploymentError attribute), 43

message (ironic_python_agent.errors.DeviceNotFound attribute), 43

message (ironic_python_agent.errors.HardwareManagerMethodNotImplemented attribute), 44

message (ironic_python_agent.errors.HardwareManagerNotFound attribute), 44

message (ironic_python_agent.errors.HeartbeatConflictError attribute), 44

message (ironic_python_agent.errors.HeartbeatConnectionError attribute), 44

message (ironic_python_agent.errors.HeartbeatError attribute), 44

message (ironic_python_agent.errors.ImageChecksumError attribute), 44

message (ironic_python_agent.errors.ImageDownloadError attribute), 44

message (ironic_python_agent.errors.ImageWriteError attribute), 45

message (ironic_python_agent.errors.IncompatibleHardwareMethod attribute), 45

message (ironic_python_agent.errors.IncompatibleNumaFormatError attribute), 45

message (ironic_python_agent.errors.InvalidCommandError attribute), 45

message (ironic_python_agent.errors.InvalidCommandParamsError attribute), 45

message (ironic_python_agent.errors.InvalidContentError attribute), 45

message (ironic_python_agent.errors.IronicAPIError attribute), 45

message (ironic_python_agent.errors.LookupAgentIPError attribute), 46

message (ironic_python_agent.errors.LookupNodeError attribute), 46

message (ironic_python_agent.errors.NotFound attribute), 46

message (ironic_python_agent.errors.ProtectedDeviceError attribute), 46

message (ironic_python_agent.errors.RESTError attribute), 46

message (ironic_python_agent.errors.ServicingError attribute), 46

message (ironic_python_agent.errors.SoftwareRAIDError attribute), 46

message (ironic_python_agent.errors.SystemRebootError attribute), 47

message (ironic_python_agent.errors.UnknownNodeError attribute), 47

message (ironic_python_agent.errors.VersionMismatch attribute), 47

message (ironic_python_agent.errors.VirtualMediaBootError attribute), 47

attribute), 47
 min_jitter_multiplier
 (*ironic_python_agent.agent.IronicPythonAgentHardwareManager*
 attribute), 39
 min_jitter_multiplier
 (*ironic_python_agent.inspect.IronicInspection*
 attribute), 67
 module
 ironic_python_agent, 82
 ironic_python_agent.agent, 37
 ironic_python_agent.api, 28
 ironic_python_agent.api.app, 27
 ironic_python_agent.burnin, 39
 ironic_python_agent.cmd, 29
 ironic_python_agent.cmd.agent, 28
 ironic_python_agent.cmd.inspect, 29
 ironic_python_agent.config, 40
 ironic_python_agent.dmi_inspector,
 41
 ironic_python_agent.efi_utils, 41
 ironic_python_agent.encoding, 42
 ironic_python_agent.errors, 43
 ironic_python_agent.extensions, 36
 ironic_python_agent.extensions.base,
 29
 ironic_python_agent.extensions.clean,
 31
 ironic_python_agent.extensions.deploy,
 32
 ironic_python_agent.extensions.flow,
 32
 ironic_python_agent.extensions.image,
 32
 ironic_python_agent.extensions.log,
 33
 ironic_python_agent.extensions.poll,
 33
 ironic_python_agent.extensions.rescue,
 34
 ironic_python_agent.extensions.service,
 34
 ironic_python_agent.extensions.standby,
 35
 ironic_python_agent.hardware, 47
 ironic_python_agent.hardware_managers,
 37
 ironic_python_agent.hardware_managers.cha,
 36
 ironic_python_agent.hardware_managers.mlnx,
 36
 ironic_python_agent.inject_files, 67
 ironic_python_agent.inspect, 67
 ironic_python_agent.inspector, 68
 ironic_python_agent.ironic_api_client,
 69
 ironic_python_agent.netutils, 70
 ironic_python_agent.numa_inspector,
 71
 ironic_python_agent.partition_utils,
 73
 ironic_python_agent.raid_utils, 75
 ironic_python_agent.tls_utils, 77
 ironic_python_agent.utils, 77
 ironic_python_agent.version, 82

N

NetworkInterface (class in
 ironic_python_agent.hardware), 62
 NONE (*ironic_python_agent.hardware.HardwareSupport*
 attribute), 61
 NotFound, 46

O

override() (in module
 ironic_python_agent.config), 40

P

parse_capabilities() (in module
 ironic_python_agent.utils), 80
 parse_dmi() (in module
 ironic_python_agent.dmi_inspector),
 41
 path (*ironic_python_agent.tls_utils.TlsCertificate*
 attribute), 77
 PollExtension (class in
 ironic_python_agent.extensions.poll),
 33
 port (*ironic_python_agent.agent.Host* *attribute*),
 37
 power_off() (*ironic_python_agent.extensions.standby.StandbyEx*
 method), 35
 prepare_boot_partitions_for_softraid()
 (in module
 ironic_python_agent.raid_utils), 76
 prepare_image()
 (*ironic_python_agent.extensions.standby.StandbyEx*
 method), 35
 private_key_path
 (*ironic_python_agent.tls_utils.TlsCertificate*
 attribute), 77
 process_lookup_data()
 (*ironic_python_agent.agent.IronicPythonAgent*
 method), 38

ProtectedDeviceError, 46

R

raise_if_needed()

(*ironic_python_agent.utils.AccumulatedFailures* method), 78

RawPromiscuousSockets (class in *ironic_python_agent.netutils*), 70

remove_boot_record() (in module *ironic_python_agent.efi_utils*), 42

remove_large_keys() (in module *ironic_python_agent.utils*), 81

Request (class in *ironic_python_agent.api.app*), 28

RequestedObjectNotFoundError, 46

rescan_device() (in module *ironic_python_agent.utils*), 81

RescueExtension (class in *ironic_python_agent.extensions.rescue*), 34

RESTError, 46

RESTJSONEncoder (class in *ironic_python_agent.encoding*), 42

run() (in module *ironic_python_agent.cmd.agent*), 28

run() (in module *ironic_python_agent.cmd.inspect*), 29

run() (*ironic_python_agent.agent.IronicPythonAgent* method), 38

run() (*ironic_python_agent.agent.IronicPythonAgent* method), 39

run() (*ironic_python_agent.extensions.base.AsyncCommand* method), 29

run() (*ironic_python_agent.inspect.IronicInspection* method), 67

run_image() (*ironic_python_agent.extensions.standalone* method), 36

RUNNING (*ironic_python_agent.extensions.base.AgentCommand* attribute), 29

S

safety_check_block_device() (in module *ironic_python_agent.hardware*), 66

save_api_client() (in module *ironic_python_agent.hardware*), 66

Serializable (class in *ironic_python_agent.encoding*), 42

serializable_fields

(*ironic_python_agent.agent.IronicPythonAgent* attribute), 39

serializable_fields

(*ironic_python_agent.encoding.Serializable* attribute), 42

serializable_fields

(*ironic_python_agent.errors.RESTError* attribute), 46

serializable_fields

(*ironic_python_agent.extensions.base.BaseCommandResult* attribute), 30

serializable_fields

(*ironic_python_agent.hardware.BlockDevice* attribute), 47

serializable_fields

(*ironic_python_agent.hardware.BootInfo* attribute), 47

serializable_fields

(*ironic_python_agent.hardware.CPU* attribute), 48

serializable_fields

(*ironic_python_agent.hardware.Memory* attribute), 62

serializable_fields

(*ironic_python_agent.hardware.NetworkInterface* attribute), 62

serializable_fields

(*ironic_python_agent.hardware.SystemFirmware* attribute), 62

serializable_fields

(*ironic_python_agent.hardware.SystemVendorInfo* attribute), 62

SerializableComparable (class in *ironic_python_agent.encoding*), 42

serialize() (*ironic_python_agent.encoding.Serializable* method), 42

serialize() (*ironic_python_agent.extensions.base.AsyncCommand* method), 29

SerializableExtension (in module *ironic_python_agent.encoding*), 42

ServiceImpApi()

(*ironic_python_agent.agent.IronicPythonAgent* method), 38

SERVICE_PROVIDER

(*ironic_python_agent.hardware.HardwareSupport* attribute), 61

ServiceExtension (class in *ironic_python_agent.extensions.service*), 34

ServicingError, 46

set_agent_advertise_addr()

(*ironic_python_agent.agent.IronicPythonAgent* method), 38

set_node_info() (ironic_python_agent.extensions.poll.PollExtension method), 33
 SoftwareRAIDError, 46
 split_command() (ironic_python_agent.extensions.base.Execution method), 30
 split_device_and_partition_number() (in module ironic_python_agent.utils), 81
 StandbyExtension (class in ironic_python_agent.extensions.standby), 35
 start() (ironic_python_agent.api.app.Application method), 28
 start() (ironic_python_agent.extensions.base.AsyncCommandResult method), 30
 start_flow() (ironic_python_agent.extensions.flow.FlowExtension method), 32
 status_code (ironic_python_agent.errors.AgentIsBusy attribute), 43
 status_code (ironic_python_agent.errors.InvalidContentError attribute), 45
 status_code (ironic_python_agent.errors.NotFound attribute), 46
 status_code (ironic_python_agent.errors.RESTError attribute), 46
 stop() (ironic_python_agent.agent.IronicPythonAgentHeartbeater method), 39
 stop() (ironic_python_agent.api.app.Application method), 28
 StreamingClient (class in ironic_python_agent.utils), 78
 stress_ng_cpu() (in module ironic_python_agent.burnin), 40
 stress_ng_vm() (in module ironic_python_agent.burnin), 40
 SUCCEEDED (ironic_python_agent.extensions.base.AgentCommandStatus attribute), 29
 supports_auto_tls() (ironic_python_agent.ironic_api_client.APIClient method), 69
 sync() (ironic_python_agent.extensions.standby.StandbyExtension method), 36
 sync_clock() (in module ironic_python_agent.utils), 81
 sync_command() (in module ironic_python_agent.extensions.base), 31
 SyncCommandResult (class in ironic_python_agent.extensions.base), 30
 SystemFirmware (class in ironic_python_agent.hardware), 62
 SystemRebootError, 47
 SystemVendorInfo (class in ironic_python_agent.hardware), 62

T

TlsCertificate (class in ironic_python_agent.tls_utils), 77
 try_collect_command_output() (in module ironic_python_agent.utils), 81

U

UnknownNodeError, 47
 update_cached_node() (in module ironic_python_agent.hardware), 66
 update_nvidia_nic_firmware_image() (ironic_python_agent.hardware_managers.mlnx.Mellanox method), 37
 update_nvidia_nic_firmware_settings() (ironic_python_agent.hardware_managers.mlnx.Mellanox method), 37
 validate_agent_token() (ironic_python_agent.agent.IronicPythonAgent method), 39
 validate_configuration() (ironic_python_agent.hardware.GenericHardwareManager method), 55
 verify_image() (ironic_python_agent.extensions.standby.ImageDownload method), 35
 version() (in module ironic_python_agent.api.app), 28
 VERSION_MISMATCH (ironic_python_agent.extensions.base.AgentCommandStatus attribute), 29
 VersionMismatch, 47
 VirtualMediaBootError, 47

W

wait() (ironic_python_agent.extensions.base.BaseCommandResult method), 30
 wait_for_dhcp() (in module ironic_python_agent.inspector), 69
 wait_for_disks() (ironic_python_agent.hardware.HardwareManager method), 61
 work_on_disk() (in module ironic_python_agent.partition_utils), 74

`wrap_ipv6()` (*in module `ironic_python_agent.netutils`*), 71

`write_image()` (*ironic_python_agent.hardware.GenericHardwareManager method*), 56

`write_rescue_password()` (*ironic_python_agent.extensions.rescue.RescueExtension method*), 34